

KHADAS VIM4 Active Cooling Kit User Guide


[Home](#) » [KHADAS](#) » KHADAS VIM4 Active Cooling Kit User Guide 

Contents


- [1 KHADAS VIM4 Active Cooling Kit](#)
- [2 Setup](#)
- [3 OOWOW Introduction](#)
- [4 Interfaces](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

KHADAS

KHADAS VIM4 Active Cooling Kit



Setup



OOWOW Introduction

- VIM4 comes with the OOWOW embedded service.
- Use OOWOW to install your preferred OS directly from the Cloud.
- OOWOW will start automatically if the device storage is empty.
- Control VIM4 with a display and keyboard, or remotely over WiFi/LAN.
- With OOWOW you will always be in control of your VIM4.

Activate OOWOW: hold Function and press Reset

Activate Hotspot: press Function after OOWOW starts

Network Name: vim4-xxxxx (last 5 digits of serial no.)

Further information: <https://docs.khadas.com/oowow>

Website Introduction

- For more documentation and technical information, you can visit docs.khadas.com.
- If you encounter technical issues during development, seek help at forum.khadas.com.
- To purchase additional accessories, please visit shop.khadas.com.

Data Download Instruction

- Schematics: dl.khadas.com/products/vim4/schematic/
- Data sheets: dl.khadas.com/products/vim4/datasheet/
- Specification: dl.khadas.com/products/vim4/specs/
- 20 OXF: dl.khadas.com/products/vim4/dxf/
- 3D CAD: dl.khadas.com/products/vim4/cad/


After-Sales Service

Please email support@khadas.com if you have any after-sales related questions.



To get started, visit docs.khadas.com/vim4

Interfaces



Documents / Resources



[KHADAS VIM4 Active Cooling Kit](#) [pdf] User Guide
VIM4 Active Cooling Kit, VIM4, Active Cooling Kit, Cooling Kit, Kit