

Kinan SW1701 Rackmount KVM Console User Manual

Home » Kinan » Kinan SW1701 Rackmount KVM Console User Manual





User Manual

Contents

- 1 Description
- 2 Features
- 3 Rack Mounting
- **4 Opening the Console**
- **5 Specifications**
- 6 Documents /

Resources

- **6.1 References**
- **7 Related Posts**


Description

Single port console integrates the monitor, keyboard, and mouse in a 1U height device, it can be installed in a standard 19" rack. It can connect one computer to control the monitor, keyboard, and mouse.

Features


- 3 in 1 LCD console integrating the monitor, keyboard, and mouse.
- Directly connect computer or KVM switch to control single or multiple computers.
- 17.3& 18.5 LCD monitor with high brightness, high definition, and high resolution.
- Ultra-slim keyboard with 99 keys 82+17.
- Standard PS/2 touchpad.
- With release catch in the front panel.
- · Automatic-locking guide rail

Appearance



1-1 appearance


Front View



1-2 front view


- 1. LCD Monitor
- 2. Rear Bracket Slot
- 3. Display Menu Buttons
- 4. Mounting Bracket
- 5. Keyboard
- 6. Touchpad
- 7. Handle
- 8. Release Switch
- 9. Display Panel

Back View



- 1. Power input (AC or DC)
- 2. Power Switch
- 3. Ground connecting screw
- 4. PC connection port: integrating VGA, keyboard, and mouse signal

Cable Connection




1-4 cable connection

To ensure signal integrity and simplify cable layout, we strongly recommend you use high-quality cables with different lengths as shown in the above table.


Rack Mounting

A standard rack mounting kit is provided to mount the switch at a depth of 686-770mm n a standard 19" rack. For other mounting distances, the rear brackets need to be customized accordingly With one person holding the switch in place and the other person sliding the L bracket into the switch's side mounting brackets from the front to the back, then screwing the brackets to the rack. (See below installation drawing)



Opening the Console


- Power on the KVM after connecting cables.
- Power on the server or PC after power on the KVM.
- Release the release catch.



2-3 unlocking

*Note: The release catch can only do horizontal locking, it can't bear any load.


- Pull the KVM console all the way out and the slide rail automatically locked to its place.
- Rotate the LCD panel all the way back to expose the LCD screen; the LCD module can be rotated up to 108°.



2-4 open angel of the console

Closing the Console

- Close the console and the power automatically shut down.
- Push the release catch in the direction of the arrow, push the LED panel all the way in until it automatically locks up.



2-5 unlocking the slide rail

Operating the Monitor



3-1 Operating the Monitor

The LED OSD allows you to set up and configure the LED display.

Buttons	Functions			
MENU SELECT	Brings up the main menu.			
EXIT/AUTO	Exits the current menu and returns to the previous menu or exits the LED OSD. Press AUTO for automatic configuration.			
SL-/SL+	Moves the menu to make the corresponding adjustments.			
LED state	Green: Running Red: Power off or access nonstandard VESA signal Flashing green: Energy saving m ode or no signal			

Press AUTO if the screen migrates after power on or under other circumstances, then the screen auto-configures to its best display state.

Note:

- It may not be adjusted to its best state if part of the display mode is not standard VESA mode. If so, return back to the OSD menu to RESET, then it will revert back to normal.
- It is recommended to set up the display mode at 1920×1080, refresh rate of 60Hz.

Specifications

Model		SW1701		SW1801	
Computer Conn ections	Direct	1		1	
	Max	1		1	
Port emulation	Keyboard, mouse	PS/2, USB		PS/2, USB	
LCD monitor	LCD model	FHD TFT		FHD TFT	
	View area	17.3"		18.47"	
	Optimum resolution	1920×1080@60Hz		1920×1080@60Hz	
	Display color	262K		16.7 M	
	Brightness	300cd/m2 (T y p)		250cd/ m2 (T y p)	
	Contrast ratio	800: 1(T y p)		1000: 1 (T y p)	
	Pixel pitch(mm)	0.1989(H)x0.1989(W)		0.213(H) x0.213(W)	
Mouse	X/Y resolution	>1000 points / inch, (40 points/mm)			
	Scroll wheel	Support scroll wheel function			
Keyboard		99 keys (82 keys main keyboard +17 independent small numeric keyboard)			
Input power		100V-240Vac, 50-60Hz, <1.5A			
Power consumption		11W		20W	
Mounting distance		686-770mm (L=262mm Mounting bracket can be customized for Other mounting distance			
Operating temperature		0-50 °C			
Store temperature		-20-60 °C			
Humidity		0-80% RH, non-condensing			
Net weight		11kg	11.2kg		
Product dimension (Wx DxH)		448mmx560mmx42.5mm			
Package dimension (Wx DxH)		765mmx615mmx185mm			
Optional power input		-36V— -72Vdc			

<u>www.kinankvm.com</u>
@all right reserved Shenzhen Kinan Technology Co., Ltd Print date: 2022 / 03 Version: V2.1

Documents / Resources



Kinan SW1701 Rackmount KVM Console [pdf] User Manual

KVM-1508XX, KVM-1516XX, KVM-1708XX, KVM-1716XX, KVM-1508XX, Rackmount KVM Console, SW1701 Rackmount KVM Console, SW1701, SW1801

References

• III Kinan-Professional KVM over IP, LCD KVM Console, KVM Switch Manufacturer

Manuals+,