



[Home](#) » [Kipcush](#) » **Kipcush D2 Portable White Noise Sound Machine Instruction Manual** 

Contents [[hide](#)]


- [1 Kipcush D2 Portable White Noise Sound Machine](#)
- [2 Package Contents](#)
- [3 Get Started](#)
- [4 Touch Design](#)
- [5 Dial](#)
- [6 Sound Machine](#)
- [7 Specifications](#)
- [8 FCC Statement](#)
- [9 Frequently Asked Questions](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

Kipcush[®]


Kipcush D2 Portable White Noise Sound Machine




Package Contents



Smart sleep assistant: D2




User manual




USB type C cable

Get Started



- 1 Charge smart sleep assistant D2 before getting started.


-



2. Press and hold for 3 seconds
to power on or off.

3. There are two methods to reset the date and time:

- Select WIFI, the time and date will be set automatically;
- Select manually, the time and date will be set manually.



Notes:

Connect to local WLAN for date and time reset only .

Touch Design




1. Favorites Touch to access your favorite music and sleep sounds
2. Volume control Touch or touch and hold to increase volume
3. Sleep sounds Touch to play the stored sleep sounds
4. Back Touch to return to previous menu
5. Breath training Touch to start breath training
6. Volume control Touch or touch and hold to decrease volume

Dial














Dial

swipe left or right to select your favorite dial.



Sound Machine

1. Touch the different icons  /  /  /  /  /  to select your favorite sound style and touch the sound name to play it.
2. Touch the icons  /  to adjust the volume.
3. Touch the timer  icon to set a timer.
4. Touch the icon  to return to the previous menu.
5. Touch the icon  to start playing your most recent song.



1. Vol-
2. Favorites
3. Vol+
4. Back
5. Prev
6. Sound List
7. Volume Level
8. Add to favorites
9. Play/Pause
10. Next
11. Sound Name
12. Timer


Breath Training



Touch the icon  to start breath training.

5 breath training patterns :

- Sleep 4-7-8
- Calm 4-8
- Relax 3-4.
- Stress 3-4-5
- Mind & Body 5-7



Mute on/off

Select sound
4 Built in sounds
Singing Bowl
Chord
Woman
Waves

Select duration




Mute on/off

Touch  to exit

& Return to the previous menu

- Alarm


- Timer
- System settings



When the machine switches on. short press the power on/off button to quickly turn the screen on or off .

Press and hold the power on/off button for 10 seconds to reset.

1. Flip your smart sleep assistant (front side up) to snooze or stop your alarm when it rings.
2. Flip the smart sleep assistant (front side up) to stop the current sound or music from playing.



Specifications

Features	Specification
Power input	5-9V
Battery type	Rechargeable battery
Battery capacity	5000mAh
Plastic material	ABS+PC
Charging port	USB type C Port

FCC Statement

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by

SHENZHEN LIANHUA ELECTRONIC CO.,LTD may void the FCC authorization to operate this device.Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user’s authority to operate the equipment.


RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.The device is installed and operated without restriction.
Thank you for purchasing our products.
I wish you a happy life.

Frequently Asked Questions

- **Q: How do I troubleshoot if the product is not powering on?**
A: Check if the power cable is properly connected and try plugging it into a different outlet. If the issue persists, contact customer support for assistance.
- **Q: Can I use third-party accessories with this product?**
A: It is recommended to use only accessories approved by the manufacturer to ensure compatibility and safety.

Documents / Resources

	Kipcush D2 Portable White Noise Sound Machine [pdf] Instruction Manual D2 Portable White Noise Sound Machine, D2, Portable White Noise Sound Machine, White Noise Sound Machine, Noise Sound Machine, Sound Machine
---	--

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.