

# Klein Electronics Pocket Plus Compact 2-Way User Manual

Home » Klein electronics » Klein Electronics Pocket Plus Compact 2-Way User Manual



Pocket Plus Compact 2-Way User Manual

### **Contents**

- 1 Push To Talk
- **2 Monitor Function**
- **3 Current Channel**

**Broadcast** 

- **4 Volume Adjust**
- **5 Scan Function**
- 6 Care and Cleaning
- 7 Documents / Resources
- **8 Related Posts**


### **Push To Talk**

Press 'PIT Key / Side PTT Key to transmitting release to exit.



## **Monitor Function**

Press for 2 seconds to monitor the local airwaves



### **Current Channel Broadcast**


Long press 'Channel + ' for 1.5S to know the current channel



# **Volume Adjust**

 $Toggle \ `Volume + to increase \ the \ volume. \ toggle \ ``Volume \_" \ to \ decrease \ the \ volume. \ You \ will \ hear \ a \ beep \ sound$ 

when the volume is maximum or minimum



**Breathing Light** 

After being in Standby mode for a bit. the 'breathing' light will activate. Every 5 seconds it glows for a bit.

#### **Scan Function**

The scan function is activated in No. 16 channel,
This device complies with part 15 of the FCC Rules Operation is subject to the following two conditions

- 1. This device may not cause harmful interference. and
- 2. this device must accept any interference received including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Section 15.25 Info (if applicable)

Section 15.27 Info (if applicable)

Section 15.105 statement (for digital devices)

Modules (Instructions for installation by the 'assemblers' as to the method of ensuring proper separation distance between module and antenna and user

### Care and Cleaning

To guarantee optimal performance as well as the long service life of the product please follow the tips below.

- Do not puncture or scratch the product with hard objects.
- Do not place the product in corrosive agents. solutions or water
- Do not handle the radio by Its antenna or external microphone directly.
- When not in use. keep the accessory jacks covered with the protective caps

Power off the product. and remove the battery before cleaning

- Glean up the Oust and fine particles on the product parts with a clean and dry tint-free cloth or a brush regularly
- Use a non-woven fabric with a neutral cleaner to clean the keys, control knobs, and shell after long-time use. Do not use chemical preparations such as stain removers, alcohol, sprays, or ail preparations.

### Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For a Class B digital device or peripheral, the instructions furnished to the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This radio is designed for and classified as "Occupational/Controlled Use Only", meaning it must be used only during the course of employment by individuals aware of the hazards, and the ways to minimize such hazards; NOT intended for use in a General population/uncontrolled environment DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is an antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio.

- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between the user and the device or its antenna shall be at least 2.5 cm.

**180-DAY WARRANTY!** 

Hassle Free

For warranty information contact your dealer or email <a href="mailto:support@kleinelectronics.com">support@kleinelectronics.com</a>

### **Documents / Resources**



Klein Electronics Pocket Plus Compact 2-Way [pdf] User Manual PCKT, U7GPCKT, Pocket Plus Compact 2-Way, Plus Compact 2-Way, Compact 2-Way, 2-Way

