

Kmart 43106264 Arm Float Disks Instruction Manual

Home » Kmart » Kmart 43106264 Arm Float Disks Instruction Manual





ARM FLOAT DISKS Key Code: 43106264

This product is a swimming aid designed to introduce the child with swimming strokes for pool and beach use. Suitable for children who are learning to swim and want to gain confidence in the water. Recommend to save this instruction as reference for future use.

Contents

- 1 Instructions for Use
- 2 Warning
- 3 Care and storage
- 4 Documents /

Resources

5 Related Posts

Instructions for Use

- · Maximum weight: 25kg.
- This product is suitable to be used for children at age of 3-6years.
- Always wear on two arms simultaneously when using this product.
- Please allow the child time to get used to the type of buoyancy and wearing the float discs. Arm and leg movement is essential.
- One disc per each arm can be removed as child becomes more confident.
- Use only in shallow water under adult supervision.
- · Not for use in boating.

Warning

- 1. Always check the fabric and foam pieces for any signs of wear or tear. If any damage is found on the float disks, replace it immediately.
- 2. This product will not protect against drowning
- 3. Use only under a constant and competent supervision.
- 4. The supervisor should be within the arm's reach of children.

Care and storage

- Clean the fabric with water and mild washing up liquid after use. Don't clean with oil, petrol, or other solvents.
- Dry out the product thoroughly before storage.
- · Keep away from flames and hot sources.
- Store in a dry and ventilated area.

FOR AU/NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND. Made in China

Documents / Resources



Kmart 43106264 Arm Float Disks [pdf] Instruction Manual 43106264 Arm Float Disks, 43106264, Arm Float Disks, Float Disks, Disks

Manuals+,