

**Kmart**  
**43419098 Front**  
**and Rear**  
**Colorful**  
**Projection**  
**Light**



## Kmart 43419098 Front and Rear Colorful Projection Light Instruction Manual

[Home](#) » [Kmart](#) » Kmart 43419098 Front and Rear Colorful Projection Light Instruction Manual 

### Contents

- [1 Kmart 43419098 Front and Rear Colorful Projection Light](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Product Overview](#)
- [5 Installation](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)



**Kmart 43419098 Front and Rear Colorful Projection Light**



## Product Information

### Specifications

- **Keycode:** 43419098
- **Power Source:** 3 x 1.5V AAA batteries (not included)
- **Warning:** This product may produce flashes that could trigger epilepsy in sensitized individuals.

### Product Usage Instructions

#### Step 1: Installation

Unpack the product and identify all components.

#### Step 2: Disassemble Parts

Separate the necessary parts for installation.

#### Step 3: Install Batteries

Insert 3 x AAA batteries into the battery compartment following the correct polarity.

#### Step 4: Place Battery Compartment Back In

Ensure the battery compartment is securely placed back in its position.

#### Step 5: Lock the Cover

Securely lock the cover of the battery compartment.

#### Step 6: Fix to Handlebar

Use the rubber strap provided to fix the product to the handlebar.

### Power On Effect

Turn on the product to activate its features.

FAQs


• **Q: What type of batteries does the product require?**

A: The product requires 3 x 1.5V AAA batteries, which are not included in the package.







• **Q: How do I prevent triggering epilepsy with the product?**

A: Be cautious as the product may produce flashes that could trigger epilepsy in sensitized individuals. Use in well-lit environments and avoid prolonged exposure to flashing lights.

Product Overview



Installation


| Step 1  | Step 2  | Step 3  |
|---|---|---|
|  |  |  |
| Disassemble parts   | Install 3xAAA batteries   | Place battery compartment back in   |
| Step 4  | Step 5  | Step 6  |
|  |  |  |
| Lock the cover  | Fix to handlebar with rubber strap  | Power on effect   |

**WARNING:** INSERT BATTERIES IN THE CORRECT POLARITY AND ALWAYS FOLLOW THE MANUFACTURER’S INSTRUCTIONS. DO NOT MIX NEW AND USED BATTERIES, ALKALINE. STANDARD (CARBON-ZINC), OR RECHARGEABLE (NICKEL-CADMUM) BATTERIES. REMOVE BATTERIES IF PRODUCT WILL BE STORED FOR AN EXTENDED PERIOD. DISPOSE OF USED BATTERIES RESPONSIBLY.

**WARNING:** THIS PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

**Requires** 3 x 1.5V AAA batteries (not included)

**Documents / Resources**

|   |   |
|---|---|
|  | <p><a href="#">Kmart 43419098 Front and Rear Colorful Projection Light</a> [pdf] Instruction Manual 43419098, 43419098 Front and Rear Colorful Projection Light, Front and Rear Colorful Projection Light, Rear Colorful Projection Light, Colorful Projection Light, Projection Light, Light</p> |
|---|---|

**References**

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.