

Knightsbridge 10AX 2 Way Pull Cord Switch Instruction Manual

Home » Knightsbridge » Knightsbridge 10AX 2 Way Pull Cord Switch Instruction Manual

Contents

- 1 Knightsbridge 10AX 2 Way Pull Cord
- Switch
- **2 Product Usage Instructions**
- 3 Maintenance
- 4 FAQ
- **5 SAFETY**
- **6 INSTALLATION**
- 7 GENERAL
- **8 WARRANTY**
- 9 CONTACT
- 10 Documents / Resources
 - 10.1 References

>Knightsbridge

Knightsbridge 10AX 2 Way Pull Cord Switch



Product Usage Instructions

Installation

- 1. Ensure the product is placed securely in the desired location.
- 2. Refer to the installation manual for specific mounting instructions.
- 3. If unsure, seek professional assistance for installation.

Maintenance

It is important to maintain the product regularly to ensure its longevity. Follow these steps:

- 1. Use a soft dry cloth to clean the product.
- 2. Avoid using aggressive cleaning products or solvents that may damage the product.

FAQ

- Q: How should I dispose of the product when it reaches the end of its life?
- A: This product should be recycled correctly. Please check with local authorities for available recycling facilities.

INSTALLATION AND MAINTENANCE MANUAL

- These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.
- These instructions should be used to aid installation of the following products: 8300XX


SAFETY

- This product must be installed under the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- Please isolate mains before installation or maintenance
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation

- Do not overload this accessory or subject it to conditions outside its rating
- · This product is Class II double insulated
- · This product is IP20 rated

INSTALLATION

- Provide power to the required point of installation. If replacing an existing switch, make a note of the connections before removing the existing switch
- Unscrew the terminal cover
- This accessory can be mounted onto a round dry lining box or pattress. Alternatively, to surface mount, using the base plate as a template, mark the location for, and drill the fixing holes ensuring not to infringe with any gas/water pipes or electrical cables.
- Fix to a solid surface using suitable fixings
- To ensure the correct polarity is observed, carefully wire as shown in Fig. 1. The earth terminal is non-functional and only provided for convenience. Check all connections are tight with no loose strands outside the terminals
- · Refit the cover
- · Switch on and check for the correct operation



GENERAL

- This product should be recycled perfectly when it reaches the end of its life. Check local authorities for where facilities exist.
- Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents that may damage the
 product.

WARRANTY

- This product has a warranty of 1 year from date of purchase.
- Failure to install this product under the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty.
- If this product should fail within its warranty period it should be returned to the place of purchase for a free-of-charge replacement.
- ML Accessories does not accept responsibility for any installation costs associated with the replacement product.
- Your statutory rights are not affected. ML Accessories reserves the right to alter product specifications without prior notice.

CONTACT

ML Accessories Limited

- Unit E, Chiltern Park, Boscombe Road,
- Dunstable, LU5 4LT
- www.mlaccessories.co.uk

Documents / Resources



Knightsbridge 10AX 2 Way Pull Cord Switch [pdf] Instruction Manual 10AX 2 Way Pull Cord Switch, 10AX 2, Way Pull Cord Switch, Pull Cord Switch, Cord Switch

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.