

knog FROG V3 Light Twin Pack Abyss User Guide

Home » knog » knog FROG V3 Light Twin Pack Abyss User Guide 12

Contents

- 1 knog FROG V3 Light Twin Pack Abyss
- **2 OPERATION**
- **3 MOUNTING**
 - **3.1 BATTERY STATUS**
 - 3.2 CHARGING
- **4 MODES & RUNTIMES**
- 5 Documents / Resources
- **6 Related Posts**



knog FROG V3 Light Twin Pack Abyss




OPERATION



LONG PRESS ON/OFF STANDARD PRESS – CYCLES THROUGH ALL 9 MODES QUICK PRESS (WHEN SWITCHED OFF) – BATTERY STATUS

MOUNTING



PLACE THE FROG ON YOUR HANDLEBAR, SEATPOST OR ANY TUBULAR STRUCTURE ON YOUR BIKE,

BATTERY STATUS



A QUICK PRESS OF THE POWER BUTTON WHEN THE FROG IS SWITCHED OFF WILL INDICATE THE BATTERY STATUS USING THE LED ARRAY



WHEN THE BATTERY IS RUNNING LOW, THE STRAP HOOK WILL GLOW RED

CHARGING



LIFT CHARGING-PORT HATCH



INSERT USB C CHARGING CABLE



WHEN CHARGING, THE LED ARRAY WILL DISPLAY THE BATTERY STATUS. A FULLY ILLUMINATED ARRAY OF LEDS INDICATES THE FROG IS 100% CHARGED

MODES & RUNTIMES

FRONT

MODE	LUMENS	RUNTIME
High	18	4hr
Low	2	20hr
Side Flash	27	5hr
Full Bright	40	10hr
Back to Front	12	18hr
Front to Back	17	8hr
Side to Side	17	7hr
Rotation	17	18hr
Eco	10	80hr

REAR

MODE	LUMENS	RUNTIME
High	7	3hr
Low	1	15hr
Side Flash	11	4hr
Full Bright	20	7hr
Back to Front	5	13hr
Front to Back	8	6hr
Side to Side	6	5hr
Rotation	6	13hr
Eco	4	60hr

Documents / Resources





knog FROG V3 Light Twin Pack Abyss [pdf] User Guide

FROG V3 Light Twin Pack Abyss, FROG V3, Light Twin Pack Abyss, Twin Pack Abyss, Light Pack Abyss, Pack Abyss, Twin Abyss, Light Twin Abyss, Light Abyss, Light

Manuals+, home privacy