

KOBALT 9400 2 Shelf Utility Cart Instruction Manual

Home » Kobalt » KOBALT 9400 2 Shelf Utility Cart Instruction Manual



KOBALT 9400 2 Shelf Utility Cart




Contents

- **1 Package Contents**
- **2 Hardware Contents**
- 3 Safety Information
- **4 Preparation**
- **5 Assembly Instructions**
- **6 Hardware Used**
- **7 Care And Maintenance**
- **8 Customer Support**
- 9 Documents /

Resources

- 9.1 References
- **10 Related Posts**

Package Contents



PART	DESCRIPTION	QUANTITY
А	Leg	2
В	Leg	2
С	Top Shelf	1
D	Bottom Shelf	1
E	Swivel Caster	2
F	Front Caster	2
G	Cable Rack	2

Hardware Contents

(not shown in actual size)

• M6 x 25 mm Phillips Head Screw Qty. 4





• M8 x 40 mm BoltQty. 16





• M8 mm Spring Washer Qty. 16





• M8 mm Hex Nut Qty. 16







A Safety Information

Please read and understand this entire manual before attempting to assemble, operate or install the product.


- · Wear safety glasses when assembling this product.
- Do not alter this product in any manner. This may cause product damage or personal injury.
- Keep the product on a level surface. The product may become unstable and tip if stored or moved on an unlevel surface, and may cause personal injury or product damage.
- The maximum loaded weight for this unit is not more than 250lb. (113Kg) per shelf and 500lb.(227Kg) total.
- · Always wear safety goggles when working with tools and equipment.



• To prevent personal injury and/or property damage, distribute the weight in this item evenly.

CAUTION

- Do not stand on this product. You may fall, which may cause personal injury.
- Do not exceed a maximim load of 250lb. (113kg) per shelf.



Preparation

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Tools Required for Assembly (not included): Rubber Mallet, Phillips Screwdriver, Safety Goggles, Flathead Screwdriver, Wrench.


Assembly Instructions

1. With the top shelf (C) upside down, attach the legs (A and B) to the top shelf, as shown.

Use a rubber mallet to seat them completely in place.

Using a Phillips screwdriver, secure the legs (A and B) to the top shelf (C) with the Phillips head screws (AA) (one per leg).


Do not overtighten.




2. Position the bottom shelf (D) on the legs (A and B) as shown.

Place the front casters (F) into the pockets into the front corners of the bottom shelf, as shown. Secure them with four screws (BB), lock washers (CC), and hex nuts (DD) each.

Place the swivel casters (E) into the pockets in the back corners of the bottom shelf (D), as shown. Secure them with four screws (BB), lock washers (CC), and hex nuts (DD) each.



3. Click cable racks (G) on at your desirable place.



Hardware Used

AA	M6 x 25 mm Phillips Head Screw	x 4
BB	M8 x 40 mm Bolt	x 16
CC	M8 mm Spring Washer	x 16
DD	M8 mm Hex Nut	x 16

Care And Maintenance

- Check the overall condition of the product periodically.
- Tighten any loose bolts and repair or replace any broken parts.

WARRANTY

This item carries a Limited Lifetime warranty from the date of purchase against defective parts and workmanship. The warranty does not cover damage due to mishandling or abuse. This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

Customer Support

KOBALTand logo design are trademarks or registered trademarks of LF, LLC. All rights reserved.

Thank you for purchasing this KOBALT product.

Questions, problems or missing parts?

Before returning, contact us on:

888-356-2258, 8 a.m. – 8 p.m., EST, Monday – Sunday or ascs@lowes.com.



Documents / Resources



KOBALT 9400 2 Shelf Utility Cart [pdf] Instruction Manual 9400 2 Shelf Utility Cart, 9400, 2 Shelf Utility Cart, Utility Cart, Cart

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.