



KODLIX Mini Wireless Keyboard User Manual


[Home](#) » [KODLIX](#) » KODLIX Mini Wireless Keyboard User Manual



MINI WIRELESS KEYBOARD
Model No: MK1













Input 5V 200mA Max


Design by Hong Kong Made in China



1. Battery LED

- 2. Work LED
- 3. Microphone
- 4. ON/OFF Switch
- 5. USB charging

	Search		Play/Pause/Mute
	Explorer		Mouse Left
	Email		Mouse Right
	Setting		Rewind (for stock video player)
	Close the window		Fast Forward (for stock video player)
	Zoom in/Zoom out		Mouse / MIC Switch (Mouse: press one time, turn mouse On/Off MIC: Long press for recording]



6. USB Receiver 7. Back cover





Contents

[[hide](#)

- [1 Installation](#)
- [2 General keyboard shortcuts](#)
- [3 Kindly note](#)
- [4 Contact Us](#)
- [5 After-sale Service](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Installation








- 1. Open the back cover on the back of the keyboard
- 2. Remove the USB receiver.
- 3. Plug the micro receiver into a USB port on your compatible electronic device.

			
Family Theater	Meeting	PC	Tablet

What’s in the box
1 x Keyboard
1 x USB Receiver
1 x Charging Cable
1 x User Manual

Specifications
Product Size : 131 x73x 13.4mm
Weight: 115g
Remote Control Distance: 10m
Working Current: 10mA
The Standby Current: 6mA
Dormancy Current : 0.01mA
Battery Capacity: 500mA

General keyboard shortcuts

Ctrl + x	Cut the selected item.
Ctrl + C	Copy the selected item.
Chi + V	Paste the selected item.
Ctrl + Z	Undo an action
CM + N	Open a new window
CM + Tab	Move forward through tabs.
Alt + Tab	Switch between open apps.
Alt + Enter	Open the Properties dialog box for the selected item.
Alt + Esc	Cycle through items in the order in which they were opened.
At + Spacebar	Open the shortcut menu for the active window.
 + L	Lock your PC.
 + D	Display and hide the desktop.
 + P	Choose a presentation display mode.
 + Shift + S	Take a screenshot of part of your screen.
 + Chi + D	Add a virtual desktop.
 + Up arrow	Maximize the window.
 + Down arrow	Remove the current app from the screen or minimize the desktop window.

Kindly note

1. Low Battery Warning

When the battery is low, Red LED will flash continuously, please charge it asap.

2. Indication LED

Blue LED indicates connection and working status;

Red LED indicates charging status;

Red LED Constantly ON: Charging is ongoing.

OFF: Charging is completed.

3. Re-pairing of USB Receiver- If similar USB receivers are mixed, please follow these steps to repair

1. Press ESC+ENTER simultaneously, blue light flashes;

2. Insert the USB receiver into the corresponding device;

3. Blue light stops flashing, pairing is completed;

4. How to switch between white and yellow characters – Press Fn

Contact Us

Address: UNIT 04, 7/F, BRIGHT WAY TOWER, NO. 33 MONG KOK ROAD, KOWLOON, HK.

After-sale Service

Email: support@kodlix.com

After-sale Service

Email: support@minisforum.com

Web: <http://www.minisforum.com>




<http://www.facebook.com/kodlix>



Join the KODLIX Forum at www.kodlix.com



Documents / Resources

	KODLIX Mini Wireless Keyboard [pdf] User Manual Mini Wireless Keyboard, MK1
---	--