Manuals+ — User Manuals Simplified.



kogan com KAKYBDCPLTA Low Profile Wireless Keyboard **User Guide**

Home » Kogan com » kogan com KAKYBDCPLTA Low Profile Wireless Keyboard User Guide 🖔



kogan com KAKYBDCPLTA Low Profile Wireless Keyboard



Contents

- 1 COMPONENTS
- **2 INSTALLATION**
- **3 OPERATION**
- **4 SPECIFICATIONS**
- **5 Customer Support**
- 6 Documents /

Resources

- **6.1 References**
- **7 Related Posts**

COMPONENTS

• Wireless Keyboard



USB Receiver



• User Guide




INSTALLATION

Battery:

- Open the battery compartment on the keyboard.
- Insert a AAA battery paying attention to the orientation of the polarity symbols.
- Place the power switch to the ON position.


Note: Remove the battery if you do not intend to use the keyboard for an extended period of time.



Wireless Connection:

- Remove the USB receiver from the battery compartment.
- Plug the USB receiver into a USB port on your computer.

Note: Ensure there are no large metal objects between the keyboard and receiver, otherwise the connection will be affected.



OPERATION

Compatibility

The following systems are supported: Windows 10, Windows 8, Windows 7, Windows Vista, Windows XP, MAC.

Multimedia Key Functions

To use the multimedia functions on your keyboard, simultaneously press the "Fn" key along with the relevant multimedia shortcut key. This combination will activate the desired multimedia feature.

• Fn+F1: Media

• Fn+F2: Volume -

• Fn+F3: Volume +

• Fn+F4: Mute

• Fn+F5: Previous Track

• Fn+F6: Next Track

• Fn+F7: Pause/Play

• Fn+F8: Stop

• Fn+F9: Decrease Screen Brightness

• Fn+F10: Increase Screen Brightness

• Fn+F11: Search

• Fn+F12: Lock Keys



Hot Keys

• My computer



Homepage



Email



Favorite



Calculator



Copilot Al Function

- The Copilot AI function button is a shortcut to deploy AI tools and features, making them more accessible and easier to use during regular computer operations.
- Press the Copilot button to activate an AI assistant to perform tasks, access information, or assist with
- The Copilot AI function is only available for Windows devices.





Copilot button

Low Battery

When the battery power is low, the battery indicator will flash. The battery will need to be replaced.

SPECIFICATIONS

Key numbers	109 + 5 hot keys
Dimensions	430×135×25.8mm
Weight	450g±20
Switch travel distance	2.0±0.1mm
Peak force	55±7g
Operating temperature (°C)	0-50
Non-operating temperatures (°C)	-10-60
Operating humidity	20%- 90% RH
Key life cycle	8,000,000 times
Power voltage	1.5V
Power current	Max. 3mA
Battery	x1 AAA (not included)
Mode	2.4G
Keystroke life	10 million lifetimes
Layout	US layout
Interface type	USB receiver
Compatibility	*Windows, MacOS, Android

^{*(}Copilot AI function is only available for Windows)

Customer Support

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help.kogan.com



Documents / Resources



kogan com KAKYBDCPLTA Low Profile Wireless Keyboard [pdf] User Guide KAKYBDCPLTA, KAKYBDCPLTA Low Profile Wireless Keyboard, Low Profile Wireless Keyboard, Profile Wireless Keyboard, Keyboard

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.