



# kogan 2-In-1 Bluetooth Selfie Stick And Tripod User Guide

[Home](#) » [Kogan](#) » kogan 2-In-1 Bluetooth Selfie Stick And Tripod User Guide 

## Contents

- [1 QUICK START GUIDE](#)
- [2 2-IN-1 BLUETOOTH SELFIE STICK & TRIPOD](#)
- [3 SAFETY & WARNINGS](#)
- [4 OPERATION](#)
  - [4.1 How to use](#)
  - [4.2 Important notes](#)
- [5 SPECIFICATIONS](#)
- [6 NOTES](#)
  - [6.1 Need more information?](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

kogan.com

## QUICK START GUIDE



## 2-IN-1 BLUETOOTH SELFIE STICK & TRIPOD

## SAFETY & WARNINGS

- Read all instructions before using the appliance and retain this guide for reference.
- Do not allow the product to be near fire or water.
- Do not place heavy objects on the product.
- Avoid using the product in high temperature or high humidity conditions, as this will reduce the product's lifespan.
- This appliance contains no user-serviceable parts. If it suffers any failure or damage, cease usage and contact Kogan Support.

## OPERATION

### How to use

1. Press and hold the button for 2 seconds to power the unit on: the LED indicator will illuminate accordingly.  
Scan for the appliance in the Bluetooth settings on your mobile device, then pair with it when visible.
2. Click the button to take photos. The LED will flash when a photo has been taken successfully.
3. If no actions or pairing take place for 3 minutes, the appliance will power off automatically.
4. If the appliance is paired but no action takes place for 10 minutes, it will power off automatically.
5. Press and hold the button for 3 seconds to power the unit off; the LED indicator will flash three times accordingly.

### Important notes

- Compatible with Android OS 4.2.4 and above, or iOS 5.0 and above.
- Young children and infants may not use the appliance, as the battery components pose a swallowing hazard.
- Fast charging will be used automatically with mobile phones which support it.

## SPECIFICATIONS

Main material	Stainless steel
Mount holder	55-85mm
Collapsed length	190mm
Extended length	1000mm
Product reference	43 x 35 x 190-1000mm
Weight	196g
Battery	CR1632 (Replaceable)

- Compact and lightweight for easy portability.
- Extendable up to 4 stages with fully adjustable extension.
- Camera angle adjusts up to 200° horizontally.
- Adjustable arm extends from 5.5cm to 8.3cm.

## NOTES

---

---

---

---

---


---

Need more information?

This is a **Quick Start Guide** and we hope that this has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to [help.kogan.com](http://help.kogan.com)



## Documents / Resources

 <p>QUICK START GUIDE kogan.com</p> <p>2-IN-1 BLUETOOTH SELFIE STICK &amp; TRIPOD</p>	<p><a href="#">kogan 2-In-1 Bluetooth Selfie Stick And Tripod</a> [pdf] User Guide</p> <p>2-In-1 Bluetooth Selfie Stick And Tripod</p>
--	--