

**kogan®**  
**KAPCSTDK12A**  
**Stream Deck 15**  
**Programmable Visual**  
**Keys and LCD Display**



# Kogan KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display User Guide

[Home](#) » [Kogan](#) » Kogan KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display User Guide 

## Contents

- [1 Kogan KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display](#)
- [2 Product Usage Instructions](#)
- [3 Components](#)
- [4 Installation](#)
- [5 Specifications](#)
- [6 FAQ](#)
- [7 CONTACT](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

**kogan®**

**Kogan KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display**



## Product Usage Instructions

### Installation

- Connect the Stream Deck to a USB port on your PC/Mac and launch the corresponding application. Avoid connecting via a USB hub/deck.

### Customization

- Launch the Stream Deck application to customize the Stream Deck.
- Drag actions from the right panel and drop them onto your desired keys.
- Configure your actions and personalize keys using custom icons. Ensure the icons are 126×126 pixels in .jpg or .png format for best results.

### Creating Folders and Actions

- Drag and drop 'Create Folder' onto a key.
- Drag and drop actions into that folder.
- To exit a folder and return to the main configuration screen, tap the back key.

### Key Management

- Right-click keys to copy, paste, or delete them.

### Stand Attachment

- Attach the Stream Deck to the supplied stand for optimal viewing.

## Components



Stream Deck



USB-C to USB-A Cable




User Guide

## Installation


1. Download and install the Stream Deck software.
  - Windows users, follow the link to download: the Windows
  - macOS users, follow the link to download: macOS
2. Connect the Stream Deck to a USB port on your PC/Mac and then launch the corresponding application.

### Note:

Connecting via a USB hub/deck is not recommended.




3. Launch the Stream Deck application to customize Stream Deck. Drag actions from the right panel and drop them onto your desired keys.




4. Configure your actions and personalize keys using custom icons.

**Note:**


For best results use 126×126 pixels .jpg or .png files.




5. Drag and drop "Create Folder" onto a key. Then drag and drop actions into that folder. Tap the back key to exit a folder and return to your main configuration screen.



6. Right-click keys to copy, paste, or delete them.



7. Attach the stream deck to the supplier stand for optimal viewing.



## Specifications

- Number of keys: 15
- Voltage/Current: 5V/0.6A
- Power consumption: 3.0W
- Connection method: Wired
- Interface: USB-C
- Backlight: LCD
- Dimensions: 131 x 80.2 x 55.5mm
- Net weight of the unit: 188g
- Material of Keycaps: Acrylic
- Material of Top panel/ Bottom Shell/Plate: ABS
- Switch: Silicone
- LCD Display: 10.8 x 52mm
- Colours: White/Black
- Operating Systems: Windows 7 64bit or later macOS 10.15 or later

## Disposal

This marking indicates that this appliance should not be disposed of with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.



## FAQ

- **How do I dispose of the Stream Deck?**

- The Stream Deck should not be disposed of with other household wastes. Recycle responsibly to promote sustainable reuse of material resources.


- **Where can I find more information?**

- For the most up-to-date guide and additional assistance, visit [help.kogan.com](https://help.kogan.com).

## CONTACT

- Need more information?
- We hope that this user guide has given you the assistance needed for a simple set-up.
- For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to [help.kogan.com](https://help.kogan.com).

## Documents / Resources

 <p>User Guide</p> <p>Stream Deck</p>	<p><a href="#">Kogan KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display</a> [pdf]</p> <p>User Guide</p> <p>KAPCSTDK12A, KAPCSTDK12A Stream Deck 15 Programmable Visual Keys and LCD Display , KAPCSTDK12A, Stream Deck 15 Programmable Visual Keys and LCD Display, 15 Programmable Visual Keys and LCD Display, Visual Keys and LCD Display, LCD Display, Display</p>
--	---

## References

- [Kogan Help Centre](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.