



Home » Kogan » Kogan NBLOOPLASSA Loop Lasso User Guide

Kogan NBLOOPLASSA Loop Lasso User Guide

May 28,

2025

Contents [hide]

- 1 NBLOOPLASSA Loop Lasso
- 2 Product Information
 - 2.1 Specifications:
- 3 Product Usage Instructions
 - 3.1 Charging:
 - 3.2 Rope Installation:
- 4 FAQ (Frequently Asked Questions)
 - 4.1 Q: How long does it take to fully charge the loop lasso?
 - 4.2 Q: How many ropes are included in the package?
 - 4.3 Documents / Resources
 - 4.3.1 References

NBLOOPLASSA Loop Lasso

"

Product Information

Specifications:

• Product Name: Loop Lasso

- Model Number: NBLOOPLASSA
- · Components:
 - Loop lasso
 - Rope (x1 green, x1 blue)
 - USB charging cable

Product Usage Instructions

Charging:

- Connect the USB charging cable into the USB-C port on the rear of the loop lasso.
- Connect the other end of the charging cable to a USB power adapter (not supplied) or a vacant USB port on your computer/laptop.
- 3. The loop lasso will be fully charged in approximately 3-5 hours.

Rope Installation:

- 1. Open the cover.
- 2. Place the rope in the slot.
- 3. Replace the cover pressing firmly.
- 4. Press the button to start.

For more information:

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help.Kogan.com.

FAQ (Frequently Asked Questions)

Q: How long does it take to fully charge the loop lasso?

A: The loop lasso will be fully charged in approximately 3-5 hours.

Q: How many ropes are included in the package?

Q. How many ropes are included in the package:		
A: The package includes one green rope and one blue rope.		
<u>View Fullscreen</u>		

Loop Lasso NBLOOPLASSA

Components

Loop lasso

Rope (x1 green, x1 blue)

USB charging cable

Operation

Charging

Connect the USB charging cable into the USB-C port on the rear of the loop lasso. Connect the other end of the charging cable to a USB power adapter (not supplied) or a vacant USB port on your computer/laptop. The loop lasso will be fully charged in approximately 3-5 hours.

Rope Installation

- 1. Open the cover.
- 2. Place the rope in the slot.
- 3. Replace the cover pressing firmly.
- 4. Press the button to start.

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help. Kogan.com.

Documents / Resources



Kogan NBLOOPLASSA Loop Lasso [pdf] User Guide

NBLOOPLASSA, NBLOOPLASSA Loop Lasso, NBLOOPLASSA, Loop Lasso, Lasso

References

- User Manual
 - Nogan, Lasso, Loop Lasso, NBLOOPLASSA, NBLOOPLASSA Loop
- Kogan Lasso

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *	
Name	
Email	
A. 1. 3	
Website	

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.