

kogan
OVCHSTD3
Series 3 Drawer
Storage Chest



kogan OVCHSTD3 Series 3 Drawer Storage Chest User Guide

[Home](#) » [Kogan](#) » kogan OVCHSTD3 Series 3 Drawer Storage Chest User Guide 

Contents

- [1 Kogan OVCHSTD3 Series 3 Drawer Storage Chest](#)
- [2 Components](#)
- [3 Assembly](#)
- [4 Specifications](#)
- [5 Assembly Steps](#)
- [6 Product Usage](#)
- [7 Frequently Asked Questions](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)




Kogan OVCHSTD3 Series 3 Drawer Storage Chest




Components


Lay all components out on a clean floor and ensure all parts are included. If any pieces are missing, check all packaging thoroughly, then contact [help.Kogan.com](https://help.kogan.com) for assistance.



1



2




3



4 (x2)



5 (x4)



6 (x4)



7 (x4)



8



9 (x6)



10 (x3)



11 (x3)



12 (x3)

Assembly

Do not fully tighten the screws until the entire assembly is complete.

Specifications

- Product Name: 3 Drawer Storage Chest
- Models: OVCHSTD3DCA, OVCHSTD3WAA, OVCHSTD3WBA






Product Information


The 3 Drawer Storage Chest is a versatile storage solution for organizing your belongings. With multiple drawers, it provides ample space to keep your items neatly stored and easily accessible. The chest is designed to be sturdy and functional, making it ideal for use in various rooms of your home.

Assembly Steps

Step 1




Assemble components 1, 2, 4 (x2), 6 (x4), 8 as shown in the manual.


				
1	2	4 (x2)	6 (x4)	8



Step 2



Continue assembly with components 3, 7 (x4), 8 as per the instructions provided.

		
3	7 (x4)	8








Step 3


Proceed with components 5 (x4) according to the manual.




Step 4

Complete assembly by adding components 8, 9 (x6), 10 (x3), 11 (x3), and 12 (x3) in the specified order.

				
8	9 (x6)	10 (x3)	11 (x3)	12 (x3)



Step 5



Product Usage

Once assembled, the 3 Drawer Storage Chest can be used to store various items such as clothing, accessories, documents, and more. The drawers can be easily opened and closed to access your belongings conveniently.

For Further Assistance

If you require more information or assistance beyond this user guide, please visit [help.Kogan.com](https://help.kogan.com) for the most up-to-date instructions and additional support.

Frequently Asked Questions


Q: What should I do if I find missing parts during assembly? A:

If you discover any missing components while assembling the chest, carefully check all packaging materials. If the parts are still missing, please contact help.kogan.com for further assistance.

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help.kogan.com

Documents / Resources

<div><div>User Guide</div><div>OVELA</div><div></div><div>3 Drawer Storage Chest</div></div>	<p>kogan OVCHSTD3 Series 3 Drawer Storage Chest [pdf] User Guide OVCHSTD3DCA, OVCHSTD3WAA, OVCHSTD3WBA, OVCHSTD3 Series 3 Drawer Storage Chest, OVCHSTD3 Series, 3 Drawer Storage Chest, Storage Chest, Chest</p>
--	---

References

- 🔌 [Kogan Help Centre](#)
- [User Manual](#)

Manuals+, [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.