



Contents [[hide](#)]

[1 Kogan OVCHSTD8DBA 8 Drawer Storage Chests](#)

[2 Assembly](#)

[3 Step 5](#)

[4 Step 6](#)

[4.1 Specifications](#)


[4.2 FAQs](#)

[5 Documents / Resources](#)

[5.1 References](#)



Kogan OVCHSTD8DBA 8 Drawer Storage Chests



Safety & Warnings

Warning

Children have died from furniture toppling over.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb, or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Place heavy items down low.



NEVER put a TV on this furniture.


Components

Lay all components out on a clean floor and ensure all parts are included. If any pieces are missing, check all packaging thoroughly, then contact help.[Kogan.com](https://www.kogan.com) for assistance.


1. Top Panel
2. Left Frame
3. Right Frame
4. Middle Frame
5. Bottom Rail (x2)
6. Adjustable Foot (x4)
7. Screw A (x6)
8. Screw B (x6)
9. Allen Key
10. Drawer Bottom (x8)
11. Drawer Front/Back (x8)
12. Wall Screw (x2)
13. Wall Plug (x2)
14. Handle (x8)
15. Screw C (x16)




1



2



3



4



5 (x2)



6 (x4)




7 (x6)



8 (x6)



9



10 (x8)



11 (x8)




12 (x2)



13 (x2)



14 (x8)



15 (x16)

Assembly



Warning


Do not fully tighten the screws until you have completed all assembly steps.

Step 1

- Use components 8 (x6) and 9.
- Assemble the frames and bottom rails using Screw B and the Allen Key.

Step 1:



	
8 (x6)	9




Step 2

- Use components 7 (x6) and 9.
- Attach the top panel to the assembled frame using Screw A and the Allen Key.

Step 2:



	
7 (x6)	9




Step 3

- Use components 6 (x4) and 9.
- Attach the adjustable feet to the bottom of the frame using the Allen Key.

Step 3:



	
6 (x4)	9



Step 4

- Use components 12 (x2) and 13 (x2).
- Secure the unit to the wall using the wall screws and plugs.





Step 4:




Step 5

- Repeat this step 8 times until all the drawers are assembled.
- Use components 10 (x8), 11 (x8), 14 (x8), and 15 (x16).
- Assemble each drawer by attaching the front/back panels to the bottom panel, securing with screws, and attaching the handle.

Step 5: Repeat this step 8 times until all the drawers are assembled.


			
10 (x8)	11 (x8)	14 (x8)	15 (x16)



Step 6


- Insert the assembled drawers into the frame.

Step 6:



Step 7

Step 7:



Need more information?

- We hope that this user guide has given you the assistance needed for a simple setup
- For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help.kogan.com
- kogan.com

Specifications

Model	OVCHSTD8DBA & OVCHSTD8DGA
Type	8-Drawer Storage Chests

FAQs

How do I secure the furniture to the wall?

Use the provided wall screws and plugs to secure the unit to the wall as instructed in Step 4.


Can I put a TV on this furniture?

No, it is not safe to put a TV on this furniture.

What should I do if parts are missing?

Check all packaging thoroughly and contact help.[Kogan.com](https://kogan.com) for assistance.

Documents / Resources

	Kogan OVCHSTD8DBA 8 Drawer Storage Chests [pdf] User Guide OVCHSTD8DBA, OVCHSTD8DGA, OVCHSTD8DBA 8 Drawer Storage Chests, OVCHSTD8DBA, 8 Drawer Storage Chests, Storage Chests
---	---

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.