

# **KOHLER RC12 Elongated Heated Bidet Remote Control User Manual**

Home » Kohler » KOHLER RC12 Elongated Heated Bidet Remote Control User Manual

# Contents

- 1 KOHLER RC12 Elongated Heated Bidet Remote Control
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Rear cleaning
- **5 NIGHT LIGHT**
- **6 FCC Statement**
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**



**KOHLER RC12 Elongated Heated Bidet Remote Control** 



## **Product Information**

## **Specifications**

• Product Name: Intelligent Toilet Remote Control

• Usage: Control functions of the smart toilet

• Features: Hot/Cold massage, Nozzle Cleaning

Compatibility: Compatible with smart toilets

• Regulatory Compliance: FCC Part 15

# **Product Usage Instructions**

## **Remote Control Pairing**

- 1. Pull the plug off.
- 2. Press the stop button until the gear lights flicker.
- 3. Pull the plug in when the remote controller is near the product.
- 4. The gear lights should stop flickering and stay lit to indicate successful pairing.

## H/C Massage

In the cleaning mode, press the hot and cold massage button to enable alternating hot and cold water temperature for cleaning. This function is available during buttocks cleaning and women washing.

#### **Nozzle Clean:**

To clean the nozzle, press the nozzle cleaning button. The nozzle will extend, and you can use a cloth for cleaning.

#### **RF Warning:**

The device complies with general RF exposure requirements and can be used in portable conditions without restrictions.

## **FAQ**

# 1. What should I do if the remote control pairing is unsuccessful?

If the pairing process fails, ensure that the remote controller is close to the product and follow the pairing steps carefully. If issues persist, contact customer support for assistance

## 2. Can I use the H/C massage function at any time?

The hot and cold massage function is available during buttocks cleaning and women washing modes. Ensure you are in the appropriate cleaning mode before using this function.

#### 3. How often should I clean the nozzle?

We recommend cleaning the nozzle regularly for hygiene purposes. Depending on usage frequency, consider cleaning it at least once a week with a soft cloth.

#### **User Manual**

The remote control is used for intelligent toilet operation control Before use, it is necessary to check the code with the receiving device on the smart toilet.

Remote Control Pair Code:Pull the plug off→Press the stop button until the gear lights flicker →Pull the plug in when the remote controller near the product→ The gear lights stop flicking and keep lighting→Successful.



The functions that can be operated on the smart toilet are as follows

#### Flush

Press the "flush" button to flush the product

## Rear cleaning

• Press the "Rear" button. The cleaning water spurts out from the front of the nozzle, cleaning the buttocks in the previous way. Press again

## DRYER

- Press to activate the warm air dryer.
- Press again to adjust the fan speed.

#### **NIGHT LIGHT**

• Press to turn the night light on/o .

## Stop

To stop the function of buttocks cleaning or women washing, press "button or short press the knob button.\* hip cleaning and women's washing, with automatic stop function after

## H/C massage In

the cleaning mode, press the hot and cold massage button to realize alternating hot and cold cleaning of water temperature. \* this function can only be turned on/off for hot and cold massage during buttocks cleaning and women washing.

#### **Nozzle Clean**

Press the nozzle cleaning button, the nozzle is extended, and the cloth can be used for cleaning

#### **WARNING**

#### **FCC Statement**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

## RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Note**: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **Documents / Resources**



KOHLER RC12 Elongated Heated Bidet Remote Control [pdf] User Manual

RC12 Elongated Heated Bidet Remote Control, RC12, Elongated Heated Bidet Remote Control, Heated Bidet Remote Control, Control

#### References

• User Manual

# Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.