

[Home](#) » [Kramer](#) » **Kramer C-CU32/UC+H Active Multi-Format Input (M) to USB C Output (M) Adapter Cable Instruction Manual** 

Kramer C-CU32UC+H Active Multi-Format Input (M) to USB C Output (M) Adapter Cable



Contents [[hide](#)]

- [1 Step 1: Check What's In The Box](#)
- [2 Step 2: Introduction](#)
- [3 Step 3: Features](#)
- [4 Step 4: Get To Know Your C-cu32/uc+h](#)
- [5 Step 5: How To Use Your C-cu32/uc+h](#)
- [6 Step 6: Technical Specification](#)
- [7 Customer Support](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

Step 1: Check What's In The Box

- ✔ C-CU32/UC+H Active Multi–Format Input (M) to USB C Output (M) Adapter Cable.
- ✔ 1 Installation guide.

Step 2: Introduction

Congratulations on purchasing your Kramer C-CU32/UC+H Active Multi–Format Input (M) to USB C Output (M) Adapter Cable.


The C-CU32/UC+H supports full USB-C 3.2 features (when the input is HDMI, need to connect the USB 3.2 A type connector).

The adaptor is perfect for BYOD meeting rooms as a direct connection between the Laptop to the USB-C monitor, or in a big meeting room by connecting it between the laptop to the under the desk USB-C switcher (for example, for SWT-31-HU-TR, it is recommended to set the input EDID to 4K@30 4:4:4).

Step 3: Features

- High–Performance Adapter Cable — Supports 4K@30Hz (4:4:4) digital video connectivity.
- USB 3.2 data (10Gbps)
- 60W power charging
- Active Adapter — Retimes the signal to ensure full resolution and USB 3 signal quality.
- Simplifies Equipment Requirements — Replaces multiple separate cables, adapters, and dongles with a single multi head cable.
- Plug and Play Installation — No software required.
- 2.7 Meter Cable Output.
- RoHS, REACH, CE & FCC Compliant.

Step 4: Get To Know Your C-cu32/uc+h



#	Feature	Function
1	USB 3	To connect to USB devices like speakerphones, web camera (when the input is HDMI).
2	USB-C Output	To connect to USB-C monitor, or any other Active USB-C signal management device (like Kramer SWT3-31-HU-TR).
3	USB-C Input	To connect to a laptop with USB-C port.
4	HDMI Input	To connect to a laptop with HDMI port.

Step 5: How To Use Your C-cu32/uc+h

i Devices connected to the C-CU32/UC+H USB-C Output (#2 above), require their own power source.

In case your laptop has only HDMI port:

- Connect the HDMI (# 4) input of the C-CU32/UC+H to the laptop.
- Connect the USB 3 type A to (# 1) to the USB port on your laptop.
- Connect the USB-C output (# 2) to a USB-C monitor.

In case your laptop has USB C port:

- Connect the USB-C input (# 3) of the C-CU32/UC+H to the laptop.
- Connect the USB-C output (# 2) to a USB-C monitor.

Step 6: Technical Specification

Overall	Type	USB 3.2 GEN–2
	Video	4K@30 4:4:4 (DP Alt Mode)
	USB 3.2 Gen 2	10Gbps
	USB 2.0	480Mbps
	Power	60W
Physical	Connector 2&3	USB Type–C Male Gold-plated
	Connector 1	USB 3.0 Type–A Male Gold-plated
	Connector 4	HDMI Male Gold plated
Jacket	Material	PVC
	Color	Black
	Diameter	5 ±0.2mm
	Bending Radius	30
Electrical	Temperature Rating	50°C
	Voltage Rating	30V
Standards Co mpliance	Safety	CE, FCC
		ROSH, REACH

Customer Support




Scan to go to website

C-CU32/UC+H Installation Guide

This guide helps you install and use your C-CU32/UC+H for the first time.

Go to www.kramerav.com/downloads/C-CU32/UC+H to download the latest user manual and check if firmware upgrades are available.

kramerav.com



Documents / Resources

	Kramer C-CU32/UC+H Active Multi-Format Input (M) to USB C Output (M) Adapter Cable [pdf] Instruction Manual C-CU32, UC H Active Multi Format Input M to USB C Output M Adapter Cable, C-CU32 UC H, Active Multi Format Input M to USB C Output M Adapter Cable, Multi Format Input M to USB C Output M Adapter Cable, Input M to USB C Output M Adapter Cable, M to USB C Output M Adapter Cable, to USB C Output M Adapter Cable, USB C Output M Adapter Cable, Output M Adapter Cable, Adapter Cable, Cable
---	---

References

- [User Manual](#)

■ Kramer

◆ Active Multi Format Input M to USB C Output M Adapter Cable, Adapter cable, C-CU32, C-CU32 UC H, Cable, Input M to USB C Output M Adapter Cable, Kramer, M to USB C Output M Adapter Cable, Multi Format Input M to USB C Output M Adapter Cable, Output M Adapter Cable, to USB C Output M Adapter Cable, UC H Active Multi Format Input M to USB C Output M Adapter Cable, USB C Output M Adapter Cable

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.