



## KREAFUNK aJAZZ Elegant Bluetooth Speaker User Manual

[Home](#) » [KREAFUNK](#) » KREAFUNK aJAZZ Elegant Bluetooth Speaker User Manual 

# KREAFUNK™

aJAZZ  
Classy Bluetooth speaker  
Operation manual



KERA FUNK EST.2011

 FLIP for Basic Functions

## Contents

### [1 SAFETY AND MAINTENANCE](#)

### [INSTRUCTIONS](#)

### [2 CONNECT & PLAY](#)

### [3 MANUAL BLUETOOTH® PAIRING MODE](#)

### [4 MULTI-FUNCTIONS](#)

### [5 VOICE ASSISTANT FUNCTION](#)

### [6 BATTERY AND CHARGING](#)

### [7 BATTERY STATUS](#)

### [8 TRUE WIRELESS STEREO PAIRING](#)


### [9 Documents / Resources](#)

### [10 Related Posts](#)

## SAFETY AND MAINTENANCE INSTRUCTIONS


1. Please read this operation manual carefully before use.
2. The safety and maintenance instructions in this operation manual should be retained for future reference and must be followed at all times.
3. Keep the product away from heat sources such as radiators, heaters, or other appliances that produce heat.
4. Do not expose the product to direct sunlight for longer periods. High temperatures will shorten the life of the product, destroy the battery and distort certain plastic parts.
5. Do not expose the product to extreme cold as it may damage the internal circuit board.
6. Avoid liquids getting into the product.
7. Do not throw with or stamp on the product. This may damage the internal circuit board.
8. Do not try to disassemble the product. This must only be done by a professional.
9. Do not use concentrated chemical products or detergents to clean the product.
10. Keep the surface away from sharp things, as these may cause damage to the plastic parts.
11. Use 5V / 1A power supplies only. The connection of power supplies with higher voltage may lead to severe damage.
12. Do not arbitrarily discard or place the lithium battery near fire or intense heat in order to avoid a risk of explosion.

If you do experience any problems with your product please contact the retailer you purchased the product from. The retailer will provide you with guidance and if that does not solve the problem, the retailer will handle the claim directly with KREAFUNK.




## CONNECT & PLAY

①




Press the multifunction button (K) to turn aJAZZ on. The LED indicator will light up white and a sound prompt is heard.



When the LED indicator on jazz starts flashing white, make sure Bluetooth on your device is turned on. Find the list of visible/connected units on your device and select “aJAZZ”. The LED indicator will turn solid white, a sound prompt is heard and aJAZZ is ready to play.


## MANUAL BLUETOOTH® PAIRING MODE



aJAZZ will always reconnect to the last connected device when turned on. If you wish to connect a new device, you can manually activate Bluetooth® pairing mode:

Press and hold the multifunction button (K) to activate Bluetooth pairing mode. The LED indicator will flash white and you can now pair aJAZZ with a new device.

## MULTI-FUNCTIONS




## VOICE ASSISTANT FUNCTION


You can use your device's Voice Assistant through the built-in microphone on jazz. Activate your Voice Assistant by triple-pressing the Play button.

The LED indicator will flash white and the built-in microphone will pick up your voice commands.

When having two aJAZZs playing in TWS mode, only one aJAZZ can activate the microphone for Voice Assistant. When activating your Voice Assistant, the LED indicator will flash white on the speaker that listens to your commands.



## BATTERY AND CHARGING

















### CHARGING:

Charging time is approximately 4 hours using the included USB cable. The LED indicator flashes orange when charging. The LED indicator turns solid green when the battery is fully charged.


Playing time on a full charge is approximately 15 hours (50% volume).

### BATTERY STATUS

LED	Battery Status
White 	 15-100 %
Red 	 <15 %
Flashing Red 	 <10 %
Orange   	 0-99 %
Green   	 100 %


When the battery level is below 15%, the LED indicator turns solid red. When the battery level is below 10%, the LED indicator flashes red. aJAZZ will automatically switch off when not in use for 60 minutes.

### TRUE WIRELESS STEREO PAIRING



aJAZZ can pair with another aJAZZ and play in True Wireless Stereo (TWS).

Turn on both jazz. Press and hold the multifunction button (K) on the primary speaker. Simultaneously press the (+) button to activate TWS pairing mode. The LED indicator on the primary speaker now flashes purple. Press and hold the multifunction button on the secondary speaker to connect in TWS.



The two jazz will automatically pair, the LED indicator will turn solid white on both speakers and a sound prompt will be heard.

Make sure your device is paired with the primary speaker. You are now ready to play in True Wireless Stereo.

The two jazz will automatically reconnect in TWS mode when both speakers are turned on until TWS pairing mode is manually activated again on one of the speakers.

## TECHNICAL SPECIFICATIONS

- 15 hours playing time (50% volume)
- Bluetooth 5.0
- 6W digital amplifier
- Can be paired in stereo
- Built-in microphone for the hands-free speech function
- Dust and water repellent (IP55)

- Charger cable with USB to USB-C included
- Simple operation via the multifunction button
- Dimensions: 80x39mm (ØxH)
- Weight: 400g


This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The declaration of conformity may be consulted at:

[www.kreafunk.com/declaration-of-conformity/](http://www.kreafunk.com/declaration-of-conformity/)



## Documents / Resources

	<p><a href="#">KREAFUNK aJAZZ Elegant Bluetooth Speaker</a> [pdf] User Manual aJAZZ, Elegant Bluetooth Speaker</p>
---	--

[Manuals+](#)