Home » Kruger and Matz » Kruger and Matz KM0826 Portable Radio Owner's Manual

Kruger and Matz KM0826 Portable Radio Owner's Manual

Contents

- 1 Kruger and Matz KM0826 Portable
- **2 Product Information**
- **3 Product Usage Instructions**
- **5 Product Overview**
- **6 SAFETY INSTRUCTIONS**
- **7 OPERATION**
- **8 SPECIFICATION**
- 9 Documents / Resources
 - 9.1 References
- **10 Related Posts**



Kruger and Matz KM0826 Portable Radio

Product Information

Specifications

• Brand: KM0826

• Frequency Range: FM 87.5 – 108 MHz

• Power Source: Power cable or 2D type batteries (not included)

• Features: Bluetooth connectivity, Volume control, Power switch

Product Usage Instructions

Safety Instructions

Read the entire instruction manual before you start the installation and assembly and keep it for future reference.

- 1. Protect the device from humidity, water, and other liquids.
- 2. Ensure the voltage indicated on the appliance matches the power supply socket voltage before connecting.
- 3. Avoid heat sources and extreme temperatures.
- 4. Clean the device with a soft, slightly damp cloth without abrasive agents.



- 5. If not in use for a long time, remove batteries and unplug from the power supply.
- 6. Do not disassemble the device. Contact authorized service for repairs.

Operation

To power the radio, insert 2 D-type batteries (not included).

Follow these steps:

- 1. Remove the battery cover compartment located at the rear bottom of the radio.
- 2. Insert the batteries according to the polarity markings.
- 3. Close the battery compartment securely.

CAUTION: Incorrect battery installation can damage the radio. Avoid using old or discharged batteries to prevent leakage.

Radio Operation

- 1. Set the power switch to the FM position.
- 2. Use the frequency knob to tune to your desired station.

Bluetooth Connection

- 1. Set the power switch to the BT position.
- 2. Pair with KM0826 device. An audio cue will indicate a successful pairing.
- 3. Start playing audio from the external device.

FAQ


Q: What should I do if the radio does not turn on?

A: Check the battery installation and ensure they are correctly inserted with the right polarity. If using a power cable, confirm it is connected properly and the power source is active.

Q: How can I improve Bluetooth connectivity?

A: Make sure the Bluetooth device is within range, and there are no obstacles causing interference. Try pairing again and ensure Bluetooth is enabled on both devices.

Product Overview



- 1. Speaker
- 2. Power cable socket
- 3. Antenna
- 4. Frequency indicator
- 5. Power/ Bluetooth indicator
- 6. Frequency knob
- 7. Volume control
- 8. Power switch

SAFETY INSTRUCTIONS

Read the entire instruction manual before you start installation and assembly and keep it for future reference.

- 1. Protect this device from humidity, water, and other liquids.
- 2. Before connecting the device to the power supply socket, make sure the voltage indicated on the appliance corresponds to the voltage in the power supply socket.
- 3. Protect the device from heat sources and extreme temperatures.
- 4. Clean the device with a soft, slightly damp cloth, without abrasive agents.
- 5. If the device is not going to be used for a long time, take out the batteries and unplug them from the power supply.
- 6. Never disassemble this device. In case of damage, contact the authorized service point for repair.

OPERATION

Battery installation

- To power the radio, insert 2 D-type batteries (not included). To install batteries, take out the battery cover compartment, and place it in the rear bottom of the radio. Insert the batteries according to the polarization. Close the battery compartment.
- CAUTION: incorrect battery installation may cause damage to the radio. Do not use old and discharged

batteries. They may cause leakage and damage the radio. The device may not work correctly, if the batteries are bad.

AC power

- Plug the power cable into the power socket of the radio, then plug it into the USB socket on a power adapter.
- After plugging in the power cable, the radio will disconnect the power from the batteries.
- Caution: do not connect the device to a fast charger. Risk of damaging the device.

Turning on the radio

- 1. Set the power switch to the FM position.
- 2. Use the tuning knob to set the frequency.
- 3. Use the volume knob to set the volume.
- 4. Extend the antenna, to improve the reception.

Bluetooth

- 1. Set the power switch to the BT position.
- 2. On an external device (ex. a smartphone) turn on Bluetooth and connect to the KM0826 device. After successful pairing, an audio cue will be played.
- 3. Start playing on the external device.

SPECIFICATION

- Bluetooth
- · Foldable handle
- Telescopic antenna
- Radiofrequency: 87,5 108 MHz FM
- Speaker: 5 Ohm / 2 W
 Power supply: 5 V / 1 A
- Battery power supply: 3 V (2x D battery)
- **Dimensions:** 215 x 158 x 80 mm
- Weight: 442 g

Correct Disposal of This Product



Waste Electrical & Electronic Equipment

- Applicable in the European Union and other European countries with separate collection systems This marking shown on the product or its literature indicates that it should not be disposed of with other household wastes at the end of its working life.
- To prevent possible harm to the environment or human health from uncontrolled waste disposal, please

separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources.

- Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
- Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.
- Made in China for Lechpol Electronics Leszek Sp.k., ul. Garwolińska 1, 08-400 Miętne is a registered trademark.



Documents / Resources



<u>Kruger and Matz KM0826 Portable Radio</u> [pdf] Owner's Manual KM0826 Portable Radio, KM0826, Portable Radio, Radio

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.