




Kruger Matz KM0770 Wireless Controller Owner's Manual

[Home](#) » [Kruger Matz](#) » Kruger Matz KM0770 Wireless Controller Owner's Manual 

Contents

- [1 Kruger Matz KM0770 Wireless Controller](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 PRODUCT DESCRIPTION](#)
- [4 OPERATION](#)
- [5 SPECIFICATION](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Krüger&Matz

Kruger Matz KM0770 Wireless Controller



SAFETY INSTRUCTIONS


Read this instruction manual and keep it for future reference. The producer does not take responsibility for damages caused by inappropriate handling and use of the product.

- Protect this device from extreme temperatures, sources of heat, and direct sunlight. Do not expose the device to water or humidity nor install a near a strong magnetic field.
- Do not handle this device with wet hands.
- It is suggested not to consume meals or drink during using the device. Food leftovers getting under the buttons may cause problems with operation or damage the device.
- Do not use this device if it has been damaged.
- Prevent the device from falling on the ground or being strongly impacted.
- The producer does not claim liability for any damage caused by inappropriate use and handling or any mechanical damage.
- The producer does not guarantee compatibility with every external device.
- Do not disassemble nor repair this device yourself. The device has no user-serviceable parts inside. In case of damage, contact the authorized service point for check-up or repair.
- Clean the device with a soft, slightly damp cloth. Do not use any chemical agents to clean this device.

PRODUCT DESCRIPTION

1. Analog sticks
2. D-pad

3. LB, LT buttons
4. BACK button
5. HOME button
6. START button
7. Pairing indicator/controller assignment
8. RB, RT buttons
9. Function buttons
10. Charging socket
11. Reset button
12. Wireless dongle



OPERATION

Pairing

- Connect the dongle to the USB port on a console or a PC.
- The indicator on the dongle will start flashing. Press the HOME button on the controller.
- If pairing is successful, the indicators on the dongle and the controller will light up steadily.

Tips:

- To switch between X-Input and D-Input, press and hold the HOME button on the controller (or the button on the dongle) for 5 seconds.
- The controller will turn off within 30 seconds after losing connection.
- To reset the connection, press and hold the Reset button for 5 seconds (with a small, thin object ex. paperclip).
- In Windows 10, pressing the HOME button will open up the Xbox Game Bar (if this option is enabled).
- In the Steam app, pressing the HOME button will open up Big Picture mode.

SPECIFICATION



- **Compatibility:** PC, Xbox 360, Xbox One, Xbox Series X
- **Communication:** 2,4 GHz
- **Layout:** D-Input, X-Input
- **Vibration function**
- **Charging socket:** microUSB
- **Charging:** 5 V / 0,3 A
- **Battery:** lithium-ion / 600 mAh
- **Working temperature:** 5°C ~ 35°C
- **Dimensions:** 155 x 105 x 65 mm
- **Weight:** 201 g

Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems) This marking shown on the product or its literature indicates that it should not be disposed of with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Made in China for LECHPOL ELECTRONICS

Documents / Resources

	Kruger Matz KM0770 Wireless Controller [pdf] Owner's Manual KM0770, Wireless Controller
	Kruger Matz KM0770 Wireless Controller [pdf] Owner's Manual KM0770, Wireless Controller, KM0770 Wireless Controller