




## KTC H32T13 LCD Monitor User Guide

[Home](#) » [KTC](#) » KTC H32T13 LCD Monitor User Guide 



LCD Monitor  
KTC H32T13  
Display User Guide



## Contents

- 1 H32T13 LCD Monitor
- 2 Important Safety Precautions
- 3 Product Introduction
- 4 Keys And Interfaces
- 5 Base And Wall Mount
- 6 Mounting Location
- 7 Safety Protection
- 8 Power Management System
- 9 Product Technical Specifications
- 10 Simple Problems Disposal
- 11 Documents / Resources
  - 11.1 References

## H32T13 LCD Monitor

Please read the User Guide carefully and keep it properly. The pictures involved in the User Guide are for reference only, please refer to the actual product for details.

### Important Safety Precautions

1. Please read all the instructions carefully before using the product.
2. When cleaning the display, please unplug the power cord. Please wipe the display with a soft wet cloth instead of liquid or spray cleaner. Please use LCD screen cleaner in case of a stubborn stain.
3. Do not use accessories that are not recommended by the manufacturer, or there may be dangerous.
4. When unplugging the power cord of the display or the power adapter, please hold the power plug with your hand rather than directly pull the power cord to unplug it.
5. Do not place the display near water, such as bathtub, washbasin, kitchen sink, or washing machine. Do not place the display on the wet ground, or near the swimming pool. Do not use fingers or hard objects to press the surface of the LCD screen.
6. The grooves and holes on the shell or at the back and bottom of the display are designed for the ventilation and heat dissipation of the components to ensure reliable operation. So, do not put the display on the bed, sofa, carpet, or other similar surfaces to prevent the heat dissipation holes from blocking and do not place the display near or above the radiator or heater. In addition, do not place the display in an embedded device unless adequate ventilation is provided.
7. Only the power supply type shown on the nameplate can be used for the display. Please feel free to consult the display dealer or the local power supply administration, if you have any doubts about your power supply type.
8. For safety, the display or the power adapter uses a power cord with a three-prong plug, whose third prong can only be properly grounded when used with a properly grounded socket. If your socket cannot match with the plug, please contact an electrician to replace your original socket so that the plug can give full play to ensuring safety.
9. As you may face high voltage or other dangers after removing the shell, do not repair the display by yourself. You can have it repaired by qualified maintenance personnel.
10. Please unplug the power cord of the display or the power adapter from the socket, and contact qualified maintenance personnel for repairing the display, when following cases occur:
  - a. The power cord or the plug is damaged or worn out.

- b.The display has been dropped from high or the shell is damaged.
  - c.Any obvious abnormality indicates a necessary repair.
11. Please place the display in a well-ventilated environment, which is away from strong light, high temperature, or humidity.
  12. The room temperature for the display store is -20°C ~55°C, or it may be permanently damaged.
  13. The monitor screen is fragile, so please be careful when moving or handling it!

## Indicative Description of The Regulations for the Administration of the Recovery and Disposal of Waste Electrical and Electronic Products

To care for and protect the earth better, please send it to a local manufacturer with nationally recognized qualification for recycling according to the national applicable laws and regulations on recycling of waste electrical and electronic products when you no longer need this product or at the end of its service life.

## Product Introduction

It is a kind of high-performance intelligent multiple frequency scanning display, which adopts active matrix thin film transistor LED-backlit LCD. The display is controlled through the microcomputer MCU digital technology. It is compact and lightweight, which is suitable for narrow working spaces.


Before installation, please check whether the following articles are complete in the packing box:

- LCD ×1 – Power Adapter ×1 – Screwdriver ×1
- Base ×1 – Warranty Card ×1 – User Guide ×1
- Power Cord ×1 – HDMI Signal Cable ×1

If any of above product is missing, please contact with product distributor immediately.

**Notice:** Specific accessories in order to prevail in kind. Please keep packing materials for future movement.

## Keys And Interfaces



	Initial Shortcut Keys	Enter the Function Menu
↑	Signal Source Input	Move Up
↓	Luminance	Move Down
←	Shortcut Key for Gaming Assistance	Exit and Return Previous Menu
→	Shortcut Key for Preset	Open Sub-menu and Select an Option
⦿	Turn on the display by short-pressing. Turn off the display by pressing and holding for 3 seconds.	Turn off the display by pressing and holding for 3 seconds

### Signal Cable Connection

Connect the signal cable to the HDMI or DP signal output port on the PC, then connect the other end of the signal cable to the corresponding signal input port on the LCD.

### Headset Connection


After connecting the headset, there will be audio output, and it also supports external loudspeakers.

### Power Indicator


The blue indicator represents the proper functioning of the display; the red flash indicator represents no signal state. Under the energy conservation state, the display will normally work if the signal is provided again. The display is still powered on in the standby state. Thus, unplug the power cord when you do not use the display for safety.

## Base And Wall Mount


### 1. Installing the Base:



- a. Install the base into the hole position and lock with two screws;




- b. Lock the pillar with a screw and cover the back of the base;




- c. Install the chassis into the hole position and lock with a screw;


### 2. If you want to remove the whole base, do the following:





- a. Undo the screw on the chassis;



b. Undo the screw and open the cover on the base;




c. Undo the screw on the monitor;




### Use M4 screws 100x100mm

Recommended screw length is 8mm

(If you need wall mounting bracket, you need to buy it separately)



### Mounting Location



## Ventilation

- Please leave the space around the display with the size at least shown in the figure.
- Do not cover the ventilation holes or insert anything into the shell.
- Unless there are proper ventilation conditions and adequate ventilation space around the display, do not place the display within a limited space, such as a book cabinet or a built-in closet.

## Installation Guide

- The display should be installed near an AC power socket that can be easily pluggable.
- It is recommended to use suitable wall mount brackets or a base for safety purpose.
- To prevent injury, the display should be placed on a smooth horizontal plane, or fixed on a firm wall.
- If you need to install it on a wall, it should be done by professional technicians. The improper display installation may cause instability.
- Do not place the display where it may be suffered from mechanical vibration.
- Do not place the display where insects may enter.
- Do not place the display directly facing an air conditioner, or the internal panel may condense, leading to faults.
- Do not place the display where there is a strong electromagnetic field, or it will be interfered with and damaged by the electromagnetic waves.

## Safety Protection

When the PC video signal exceeds the frequency range of the display, the display will disable the line and field synchronizing signals to protect the display. Under this circumstance, you must set the output frequency of the PC to an acceptable range for the display to work properly.

## Power Management System

Mode	Power Consumption
Normal Operation	≤54W
Standby	≤0.5W

**Remark:** All technical specifications in the User Guide and on the external packing are allowed to change without prior notice.

If there is a subtle difference between the User Guide and the actual operation, the latter shall prevail.

## Product Technical Specifications

Panel Dimension	32"
Best Operating Resolution Ratio	2560)(1440 @ 75Hz
Input Voltage	DC 12V / 4.5A
Contrast	1000:1 (TYP)
Visible Area	698.112mmx392.688mm
Pitch size for wall mount	100mmx100mm

<b>Working Environment Requirements</b> Maximum altitude Atmospheric pressure Operating temperature and humidity Storage temperature and humidity	5000m 86kpa ~ 106kpa 0 °C ~40 °C 30% ~ 90% (non-condensing) -20 °C ~55 °C 20% ~ 93% (Non-condensing)
<b>Packing Dimension and Weight</b> Display Dimension (excluding base) Packing Dimension Net Weight of Display (including base) Packing Weight	717.1 × 43.3 × 422.9mm 825×135×539mm 5.65Kg 7.8Kg

## Simple Problems Disposal

Symptoms	Disposal Methods
1. Blank screen /Power indicator does not work	Check whether the power supply is in good contact with the display and the power socket; and check whether the display is turned off.
2. Blurred,too large or too small images	Go to the "Image Settings" category menu and select "Image Auto Adjust" to make the monitor adjust automatically to correct. (Only available for monitors with VGA)
3. Dark screen	Enter the "Brightness & Contrast" menu to regulate the contrast and the brightness of the display.
4. Display overheating	Leave at least 10cm of ventilated space around the display. Do not place articles on the display.
5. Dark/light spots when powered on	It is normal. Because of the temperature difference in the environment, the backlit tube emits uneven light at the initial stage after the display turns on. However, the backlit tube will emit normal light after 20 minutes, and the dark/light spots will be eliminated at that time.
6. Image distortion, flashing, shaking	Check your computer configuration, choose the correct resolution, and reset your refresh rate.
7. Noisy signal when powered off	During the power-off of the display, there may be some noisy signals on the screen caused by the normal discharge.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



#### More Information

Please scan QR code or visit [www.ktcplay.com](http://www.ktcplay.com)

Any question or comments. Please contact: [support@ktcplay.com](mailto:support@ktcplay.com) [North America] [support.eu@ktcplay.com](mailto:support.eu@ktcplay.com) [Europe]

## Documents / Resources

	<a href="#">KTC H32T13 LCD Monitor</a> [pdf] User Guide H32T13 LCD Monitor, H32T13, LCD Monitor, Monitor
--	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.