



kvm-tec 6501 Full HD KVM Over IP Extender Instruction Manual

[Home](#) » [kvm-tec](#) » kvm-tec 6501 Full HD KVM Over IP Extender Instruction Manual 

Contents

- 1 [kvm-tec 6501 Full HD KVM Over IP Extender](#)
- 2 [Follow Chart](#)
- 3 [Quick Installation SVX1 SMARTLINE](#)
- 4 [Documents / Resources](#)
 - 4.1 [References](#)
- 5 [Related Posts](#)



kvm-tec 6501 Full HD KVM Over IP Extender




Follow Chart



Quick Installation SVX1 SMARTLINE

local/CPU–remote/CON

1. Connect the CON / Remote and the CPU / Local Unit to the included 12V 2A power supply.
2. Now connect the USB cable to a USB port on your PC and connect the other end of the USB cable to the CPU /Local Unit. Connect the keyboard and mouse to the CON / Remote Unit.
3. Connect the CPU / Local and the CON / Remote Unit with a network cable.
4. Now connect the DVI cable to the DVI socket of the PC and the other end to the DVI socket of the CPU / Local Unit (PC-in). Then connect the monitor with the DVI cable to the CON / Remote Unit.



HAVE FUN – your KVM-tec Extender is now in use for many years (MTBF approx 10 years).

We are here for you to answer your questions about installation.

Manual download www.kvm-tec.com or KVM-tec Installationchannel on our homepage. personally +43 2253 81912.

Documents / Resources



[kvm-tec 6501 Full HD KVM Over IP Extender](#) [pdf] Instruction Manual
6501 Full HD KVM Over IP Extender, 6501, Full HD KVM Over IP Extender, KVM Over IP Extender, Over IP Extender, IP Extender, Extender

References

- [Kvm-tec.com: KVM Extender over IP - Matrix Switching Systeme](http://www.kvm-tec.com)