

kvm-tec 6701 Masterline MVX Instruction Manual


[Home](#) » [kvm-tec](#) » kvm-tec 6701 Masterline MVX Instruction Manual

Contents [[hide](#)]

- [1 kvm-tec 6701 Masterline MVX](#)
- [2 Follow Chart](#)
- [3 Quick Installation MVX1 Masterline](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



kvm-tec 6701 Masterline MVX




Follow Chart



Quick Installation MVX1 Masterline

local/CPU–remote/CON

1. Connect the CON / Remote and the CPU / Local Unit to the included 12V 2A power supply.
2. Now connect the USB cable to a USB port on your PC and connect the other end of the USB cable to the CPU / Local Unit. Connect the keyboard and mouse to the CON / Remote Unit.
3. Connect the CPU / Local and the CON / Remote Unit with a network cable.
4. Now connect the DVI cable to the DVI socket of the PC and the other end to the DVI socket of the CPU / Local Unit (DVI-in). Then connect the monitor to the CON / Remote Unit with a DVI cable.
5. Then connect the PC audio with the audio cable to the Local Audio. Then connect audio / out via the audio cable
6. Almost done! Now connect the audio cable Local Audio / out to the PC Audio in and Remote Audio / out with the audio cable to the microphone.



HAVE FUN – your KVM-tec Extender is now in use for many years (MTBF approx 10 years).

We are here for you to answer your questions about installation.

Manual download www.kvm-tec.com or KVM-tec Installationchannel on our homepage. personally +43 2253 81912.

Documents / Resources



[kvm-tec 6701 Masterline MVX](#) [pdf] Instruction Manual
6701 Masterline MVX, 6701, Masterline MVX, MVX

References

- Kvm-tec.com: KVM Extender over IP - Matrix Switching Systeme