



kvm-tec KT-6031L USBflex Single DVI/USB CAT Extender Installation Guide

[Home](#) » [kvm-tec](#) » kvm-tec KT-6031L USBflex Single DVI/USB CAT Extender Installation Guide 

kvm-tec KT-6031L USBflex Single DVI/USB CAT Extender Installation Guide



Contents

- [1 Update with USB-Stick](#)
- [2 Quick Installation](#)
- [USBflex](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)


Update with USB-Stick

1. Plug the USB stick with update file into USB Flex.

- press the button on the back left (if PtP, the USB channel will be disconnected) ~ 4 sec
- wait until LED flashes orange (USB stick is scanned for updates) ~ 10-20 sec
- LED lights up specifically for 3 seconds LED red -> no update on stick found (remove stick and start at step 1)
LED green -> Update found, ready to start
- press button again
- wait until the update is completed or an error occurs (for PtP local is updated first) ~ 2-3 min (PtP ~ 5-6 min)
While update is running, LED flashes green, if data is transferred or copied, LED flashes very fast.
At the end of the update, the LED flashes orange 4 more times and then starts the reboot process (the Extender must not be disconnected from the power supply during this process!)

Quick Installation USBflex

local / CPU – remote/ CON



Misprints, errors and technical changes reserved



Documents / Resources

	kvm-tec KT-6031L USBflex Single DVI/USB CAT Extender [pdf] Installation Guide KT-6031L USBflex Single DVI USB CAT Extender, KT-6031L, USBflex Single DVI USB CAT Extender, Single DVI USB CAT Extender, USB CAT Extender, CAT Extender
	kvm-tec KT -6031L USBflex Single DVI/USB CAT Extender [pdf] Installation Guide KT -6031L USBflex Single DVI USB CAT Extender, KT -6031L, USBflex, Single DVI USB CAT Extender, DVI USB CAT Extender, CAT Extender, Extender

References

- [Kvm-tec.com: KVM Extender over IP - Matrix Switching Systeme](https://www.kvm-tec.com/)