


LAMAX Sphere2 Mini User Manual

Home » LAMAX » LAMAX Sphere2 Mini User Manual



Sphere2 MiniOperating Instructions



Contents [hide

- 1 Controls
- **2 LED Indicators**
- 3 Charging indicator
- 4 Warning:
- 5 Handsfree
- 6 Charging
- 7 Parameters
- 8 Documents /

Resources

- 8.1 References
- 9 Related Posts

Controls

1. POWER On/off (hold),

Play/pause (press),

Answer/end call (press), reject the call (hold), redial last number called (double-press in quick succession)

- 2. **VOL +** Volume up (press), next track (hold)
- 3. **VOL** Volume down (press), previous track (hold)

Other

- 4. LED
- 5. Microphone
- 6. Micro SD slot
- 7. Micro USB

LED Indicators

Flashing blue (fast)	Ready for pairing
Solid blue light	Paired with Bluetooth/Micro SD card
Flashing blue (slow)	Playing

Charging indicator

Lights up red when charging, off when fully charged.

On/Off

To turn on the speaker, hold down the **POWER** button. The LED lights up and an audio alert sounds. Hold down the same button to turn off the speaker.

Pairing

- 1. Press and hold the **POWER** button to turn on the speaker. The LED starts flashing blue and the speaker is ready to pair.
- 2. Activate Bluetooth connectivity on your phone or a similar device.
 - Select "LAMAX Sphere2 Mini" from the list of available devices. If a pairing code is required, enter "0000" and confirm. Upon successful pairing, the speaker will beep and the LED will turn blue.
- 3. Playback can be controlled either with a paired device or by directly using the speaker. During playback, the

TWS

To pair two speakers with each other, switch on the two speakers and ensure that they are not paired with any other multimedia devices. On one of them, which will act as the main one, press the **POWER** button twice in quick succession, a beep will sound.

When pairing is successful, a second beep sounds and the main speaker acts as the left channel. To unpair, the two speakers, turn off Bluetooth on your phone or other device and press **POWER** twice quickly. An audio alert sounds when the devices have been successfully unpaired.

Warning:

If you do not turn off Bluetooth on your phone or another device before unpairing and press the **POWER** button twice quickly, the speakers will not unpair but instead dial the last number called.

If you insert a Micro SD card into one of the speakers, the speakers will automatically unpair and the speaker will play from the Micro SD card. Upon removing the Micro SD card, the speakers automatically pair again.

Handsfree

When the phone is paired via Bluetooth, the Handsfree function is activated. To answer/end a call, press the POWER button; reject an incoming call by holding the POWER button; quickly press the **POWER** button twice to redial the last number dialed.

Charging

The speaker can be charged using the included USB cable from a suitable USB device – e.g., an adapter, PC, or power bank. Do not charge the speaker with an input voltage higher than 5V, as the speaker may be damaged. An audio alert will sound when the battery is running low. The LED lights up red during charging. When fully charged, the red LED switches off.

Parameters

Speaker parameters	5 W, Φ 40 mm, 150 Hz–20 kHz
Battery type	Li-lon 400 mAh
Battery life	up to 15 hours at 50% volume
Talk time	4-5 hours
Charging time	1.5 hours
Playback options	Bluetooth, Micro SD card
Wireless technology	Bluetooth 5.1
Pairing distance	up to 10 m
Dimensions	48 × 46 mm
Weight	71 g



https://www.lamax-electronics.com/downloads/lamax-sphere2-mini/manual



Documents / Resources



LAMAX Sphere2 Mini [pdf] User Manual Sphere2, Mini, Sphere2 Mini

References

• **<u>ALAMAX Electronics | EN</u>**

Manuals+, home privacy