

LAMAX
T3 Secure High
Quality Footage
Camera



LAMAX T3 Secure High Quality Footage Camera User Manual

[Home](#) » [LAMAX](#) » LAMAX T3 Secure High Quality Footage Camera User Manual 

Contents

- [1 LAMAX T3 Secure High Quality Footage Camera](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 PRODUCT FEATURES](#)
- [5 BUTTON FUNCTIONS](#)
- [6 SPECIAL FUNCTIONS](#)
- [7 BASIC OPERATION](#)
- [8 OTHER FUNCTIONS](#)
- [9 PRODUCT SPECIFICATIONS](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

LAMAX

LAMAX T3 Secure High Quality Footage Camera



Product Specifications

- **Video resolution:** High-definition
- **Viewing angle:** Wide-angle lens
- **Video format and compression:** MP4
- **Audio:** Built-in microphone and speaker
- **Display:** LCD screen
- **G-sensor:** Yes, adjustable sensitivity
- **Micro SD slot:** Supports MicroSD cards
- **Loop recording:** 1/3/5-minute intervals
- **Lock files against overwriting:** Yes
- **Auto start function:** Automatically starts with car power connection
- **Date and time display:** Available
- **Motion detection:** Records movement when the vehicle is stationary
- **Languages:** Multiple language options

Product Usage Instructions

1. Power On/Off and Basic Operations

To power on/off the device, press the POWER button for 3 seconds. In the main recording interface, press OK to start/stop recording. A red dot icon indicates recording. Long press MENU to switch modes, use UP/DOWN to navigate, and press OK for various functions.

2. Video and Photo Modes

In video recording mode, press OK to start/stop recording. For photo mode, press MENU to switch and press OK to capture a photo.

3. Playback and Settings

To playback recorded videos, 2x long press MENU, use UP/DOWN to navigate and press OK to play. Access settings by pressing MENU twice, selecting Date/Time, and making adjustments using OK, UP, and DOWN.

4. Additional Functions

- **Resolution:** Select higher values for better quality.
- **Loop recording:** Choose between 1/3/5-minute intervals.
- **White balance:** Choose optimal balance for different environments.
- **Exposure:** Adjust light and darkness levels.
- **Motion Detection:** Toggle sound recording on/off.

Frequently Asked Questions (FAQ)

• **Q: How do I activate the motion detection feature?**

A: The motion detection feature is automatically activated when the vehicle is stationary. No manual activation is required.

• **Q: Can I change the language settings of the device?**

A: Yes, you can change the language settings by accessing the settings menu and selecting the Language option.

PRODUCT FEATURES



1. POWER
2. Mounting slot
3. RESET
4. MicroSD card slot
5. LED

6. MENU
7. UP
8. DOWN
9. OK
10. Lens
11. Speaker
12. USB-C input
13. Microphone

BUTTON FUNCTIONS

1. POWER button

Press for 3 seconds to turn on/off. Press once in the main recording interface to activate the screensaver.

2. Mounting slot

Insert the suction cup mount here and secure it to the vehicle glass.

3. RESET button

Located in the „R“ hole for resetting the device.

4. MicroSD card slot

For data storage.

5. LED indicator

Flashes during recording; stable in standby mode.

6. MENU button

Short press to open the function settings menu. Hold to switch between video recording, photo taking, and gallery viewing modes.

7. UP button

Navigate to the settings menu.

8. DOWN button

Navigate down in the settings menu; press briefly during recording to toggle audio recording.

9. OK button

Confirm selections; start/stop recording in camera mode.

10. Lens

Sensor module for scene detection.

11. Speaker

Outputs device sound.

12. USB-C input

For charging, power supply during operation, and data transfer.

13. Microphone

Two microphone jacks: one for recording sound and one for receiving sound.

SPECIAL FUNCTIONS

- **Auto on/off:** Automatic start/stop with car power connection.
- **Motion detection:** Records movement in front of the camera when the vehicle is stationary.

BASIC OPERATION

- **Power on/off:** Long press the POWER button for 3 seconds.
- **Video recording mode:** Press OK to start/stop recording; the red dot on the icon indicates recording.
- **Photo mode:** Long press MENU to switch; press OK to take a photo.
- **Playback:** 2x Long press MENU to switch; use UP/DOWN to navigate; press OK to play.
- **Time Settings:** Access settings with 2x press MENU button; select Date/Time and adjust using OK, UP, and DOWN.

OTHER FUNCTIONS


- **Resolution:** Select higher values for better quality.
- **Resolution Photo:** Select higher values for better quality.
- **Loop recording:** Choose between 1/3/5-minute intervals.
- **White balance:** Choose the optimal balance for different environments. An automatic setting is recommended.
- **Exposure:** Adjust light and darkness levels; 0 value recommended.
- **Motion Detection:** The detection continuously monitors the surroundings of the vehicle and automatically responds to any changes in motion by initiating a video recording
- **Audio Recording:** Toggle sound recording on/off.
- **Date Stamp:** Display time on the playback screen.
- **G-sensor:** Locks recording in case of strong impact; adjustable sensitivity.
- **System Sounds:** Enables/disables button sound.
- **Date and time:** Select to enter the time and date. Resets when battery runs out.
- **Auto-off:** Camera turns off when no memory card is present or recording is not in progress.
- **Language:** Multiple language options.
- **Frequency:** Default 50 Hz.
- **Screen saver:** The display turns off after a set time, but the recording continues.
- **Format:** Recommended every 14 days, especially if memory is full.
- **Default Settings:** Restores original settings.

PRODUCT SPECIFICATIONS

- **Video resolution:** 1920×1080/30fps, 1440×1080/30fps, 1280×720/30fps
- **Viewing angle:** 140°
- **Video format and compression:** MJPEG, AVI
- **Audio:** Built-in microphone, can be turned off
- **Display:** 2"
- **G-sensor:** Yes
- **Micro SD slot:** 128 GB
- **Loop recording:** 1/3/5 min
- **Lock files against overwriting:** Yes
- **Auto start function:** Yes
- **Date and time display:** Yes
- **Motion detection:** Yes

- **Languages:** Czech, Slovak, English, German, Polish, Hungarian, Lithuanian
- **WDR:** Yes
- **Connectivity:** USB-C
- **Holder:** Suction
- **Power:** Supercapacitor
- **Power Interface:** 5V 1.5A
- **Power cable length:** 340 cm

Documents / Resources

 <p>LAMAX ELECTRONICS T3</p> <p>EN - USER MANUAL DE - BENUTZERANLEITUNG CS - NÁVOD SK - NÁVOD PL - INSTRUKCJA OBSŁUGI HU - FELHASZNÁLÁSI KÉZIKÖNYV SL - NAVODILA ZA UPORABO LT - VARTOTOJŲ INSTRUKCIJA</p>	<p>LAMAX T3 Secure High Quality Footage Camera [pdf] User Manual</p> <p>T3 Secure High Quality Footage Camera, T3, Secure High Quality Footage Camera, Quality Footage Camera, Footage Camera, Camera</p>
--	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.