



Home » Lapbook » Lapbook A7 N4 Gaming Monitor User Guide 📆

Contents [hide]

- 1 Lapbook A7 N4 Gaming Monitor
- 2 Introduction to Desktop
- 3 Introduction to Programs
- 4 Multitasking interface
- 5 Basic Operations
- 6 Specifications
- 7 FCC Statement
- 8 Documents / Resources
 - 8.1 References

Lapbook

Lapbook A7 N4 Gaming Monitor



IMPORTANT NOTICE


- Congratulations on your purchase of new All in one LAPBOOK A7 N4
- Any problem with this purchase?
- Give us a chance to fix it!
- Please send an email with your order
- ID and a description of your problem to support@fusion5store.com
- One of our team members will get in touch with you.

Equipment start-up

Warning: When connecting the keyboard and mouse to the all in one, make sure that the computer and other equipment are in the off state, do not switch them on.

Connect the keyboard and mouse

PC can be connected with keyboard and mouse base on Bluetooth.



Connect the all in one to the power outlet

Plug the power cord into the equipment plug and the other end into a 100—240V AC outlet and press the power button.



Introduction to Desktop

1. Windows Desktop


Windows 11 start image: On the start screen, you can see many programs fixed to the taskbar.

We strongly suggest logging into your Microsoft Account to enable all the features Windows 1 1 has to offer.



2. Cortana

Use Cortana for fast smart searching.



Introduction to Programs

- 1. Besides the application programs already fixed on the
 - Taskbar, you can also fix other applications, programs, and folders to the Start Button/ Taskbar.
 - If you want to pin more programs on the start interface, see the operation in the image below.
 - In the start menu, right-click the application you want to pin and select "Pin to Start". You can also drag the application onto the "start" screen, as follows:



- Conversely, if you want to cancel or delete a certain application in the start screen,
- Right-Click the application,
- Click the "Unpin from Start"



2. If you want to have more programs on the task bar, click the start menu, Right-Click the application, select more and 'Pin to taskbar'



Conversely, if you want to cancel or delete a certain application in the task bar Right-Click the application,

Click the "Unpin this program from task bar".



Start Menu

Start icon, Start Menu will display including: Start, Device, Setup, Share, and Search Program.



Multitasking interface

Power, Settings and Account.

- Can Change account setting/Lock/Sign out.
- Can let you set up the AIO.
- Can Sleep/Shut down/Restart the AIO.



Action Center is a notification center that also allows for quick settings such as Wi-Fi, Bluetooth etc.

Search menu



Action Center



Action Center is a notification center that also allows for quick settings such as Wi-Fi, Bluetooth etc.

If you Click the Task View (or press the icon), the running applications will be display. We can switch between and close different applications.



Basic Operations

1. Sleep, Shut down and Restart





Specifications

CPU	Intel Alder Lake-N100	
Display	1920x1080 IPS	
OS	Windows 11	
Input method	USB or bluetooth Keyboard and mouse	
DDR RAM	16GB	
Capacity	512GB	
Audio	AAC,FLAC,MP3,OGG,WAV,etc(some need	
	third party software support)	
Video	3GP,MOV,MP4,MPG,AVI,etc(some need third	
	party software support)	
E-book	Support	
Wireless network	Support WIFI	
Language	English (other languages need to be downloaded	
	from Internet)	
OTG	Support	
Temperature	-10 °C to 45 °C	

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help


This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Documents / Resources



Lapbook A7 N4 Gaming Monitor [pdf] User Guide

2AIKX-LAPBOOKA7N4, 2AIKXLAPBOOKA7N4, lapbooka7n4, A7 N4 Ga ming Monitor, A7 N4, Gaming Monitor, Monitor

References

- User Manual
- Lapbook
- ◆ 2AIKX-LAPBOOKA7N4, 2AIKXLAPBOOKA7N4, A7 N4, A7 N4 Gaming Monitor, Gaming Monitor, Lapbook, lapbooka7n4, Monitor

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.