Manuals+ — User Manuals Simplified.

LASER Multimedia Wireless Keyboard and Mouse Combo User Guide

QUICK START GUIDE
Laser Multimedia Wireless Keyboard and Mouse Combo
KBX-WKBMCOM-L

Contents

GETTING STARTED

1. Remove the battery cover from the keyboard and install a single AAA battery. Put the battery cover back on the keyboard.
2. Remove the battery cover from the mouse and install a single AA battery.
3. Remove the USB Nano receiver from the compartment in the mouse and plug it into a free USB port on your computer/laptop.

Put the battery cover back on the mouse.

4. Your wireless keyboard and mouse should automatically connect to your computer/laptop.

KEYBOARD FUNCTION HOTKEYS

- FN + F1 – Music
- FN + F2 – Decrease Volume
- FN + F3 – Increase Volume
- FN + F4 – Mute
- FN + F5 – Previous Track
- FN + F6 – Next Track
- FN + F7 – Play / Pause Music
- FN + F8 – Stop Music
- FN + F9 – Home Page
- FN + F10 – Open Default Email Program
- FN + F11 – My Computer
- FN + F12 – Open Favourites

WIRELESS MOUSE DPI SETTINGS

- DPI 800/1200/1600

TROUBLESHOOTING

1. If the computer is not detecting unplug the device and plug in again
2. Test the device on another USB port
3. Update Windows to the latest version
4. Update USB drivers to the latest version

WARRANTY
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

www.laserco.com.au

Documents / Resources

LASER Multimedia Wireless Keyboard and Mouse Combo [pdf] User Guide
KBX-WKBMCOM-L, Multimedia Wireless Keyboard and Mouse Combo, Wireless Keyboard, Wireless Mouse

References

- ↗ **Laser: The Ultimate Tech Hub for Home Entertainment, Audio, Smart Home & More**

Manuals+,