

Laser SPK-B60-040 Pulse Slim Bluetooth Speaker Instruction Manual

[Home](#) » [Laser](#) » Laser SPK-B60-040 Pulse Slim Bluetooth Speaker Instruction Manual 

Contents

- 1 Laser SPK-B60-040 Pulse Slim Bluetooth Speaker
- 2 WHAT'S IN THE BOX
- 3 SPECIFICATIONS
- 4 FEATURES
- 5 CONTROLS
- 6 BLUETOOTH PAIRING
- 7 PHONE CALLS
- 8 TROUBLESHOOTING
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts



Laser SPK-B60-040 Pulse Slim Bluetooth Speaker



WHAT’S IN THE BOX

- 1 x SPK-B60-040 Speaker
- 1 x USB Type-C Charge Cable
- 1 x 3.5mm AUX cable
- 1 x User Manual


SPECIFICATIONS

Bluetooth Version	5.0
Bluetooth Range	10 meters
Bluetooth Name	SPK-B60-040
Speaker Power	8W
Frequency	20Hz – 20KHz
Battery:	3.7V 1800mAh
Charging	5V DC
Charging Time	Approx 4 – 5hours
Battery Runtime	Approx 4 hours at 100% or 6 hours at 50%
Standby Time	10 hours

FEATURES

- Bluetooth Wireless Connectivity
- USB – Upto 32gb using FAT32 or exFAT file system only.
- Micro SD Card – Upto 32gb using FAT32 or exFAT file system only.
- 3.5mm AUX IN
- Rechargeable Battery
- RGB LED Lights

CONTROLS



<p>Volume Down</p>	<p>Hold to decrease volume.</p> <p>Tap to skip track back.</p>
---------------------------	--

Mode	Tap to change between Bluetooth, AUX, Micro SD or USB.
Volume Up	Hold to increase volume Tap to SKIP track forward
Power	Press and hold to turn device on/off.
RGB Light	Tap to cycle between 9 different LED modes or turn light off.

DC 5V	<p>Insert one end of the USB-C cable into the DC 5V port and the other end into a USB wall adapter (not included) to start charging.</p> <p>Approx. 4 – 5 hours for a full charge.</p>
AUX Input	<p>Connect a source device via the supplied 3.5mm AUX cable for music playback.</p>
USB	<p>Only MP3 files on FAT32 or exFAT file system are supported.</p> <p>Please try formatting storage to suggested file system if not detected.</p>
Micro SD Card	<p>Only MP3 files on FAT32 or exFAT file system are supported.</p> <p>Please try formatting storage to suggested file system if not detected.</p>

BLUETOOTH PAIRING

With the speaker on tap the MODE button until you reach the Bluetooth mode. Search for “SPK-B60-040” under the Bluetooth settings of device you are connecting to e.g. smartphone or tablet.

TIP

If password is requested enter 0000 or 1234

PHONE CALLS

- When there is an incoming call, the speaker will ring to alert you of the call any current playback will be paused.
- Tap the power button to answer or press and hold the power button for 2 seconds to reject the call.
- When the call is finished, tap the power button to hang up. If the speaker is connected to a smartphone, tapping the power button twice will redial the last number.

TROUBLESHOOTING



<p>No Power</p>	<p>Check battery level and charge if required.</p> <p>Try turning on speaker while connected to a powersource.</p> <p>Try charging the speaker with USB Wall Adapter like a smart phone charger instead of a laptop/computer.</p>
<p>USB or Micro SD Card not recognised or files not playing</p>	<p>Make sure the USB or Micro SD Card is 32gb or less.</p> <p>Check the USB or Micro SD Card has been formatted to the FAT32 or exFAT file system. If the USB/Micro SD Card is new out of the box, we recommend you format it on a Windows based computer first before copying music to it, then using with the speaker.</p> <p>Make sure to only use MP3 music files copied to the USB or Micro SD Card.</p>

<p>Cannot find speaker when searching for Bluetooth devices</p>	<p>Make sure the speaker is in Bluetooth pairing mode.</p> <p>Try turning the speaker off then on and try again.</p> <p>Try turning off then on the device you are pairing to Bring the speaker closer to the device you are pairing to. If there are any unidentified devices on your Bluetooth search list, try selecting the top or bottom option to see if it pairs with the speaker.</p>
---	---

WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates. Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange where possible for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage. Please retain your receipt as proof of purchase.

How to make a product warranty claim

- Find your receipt with date of purchase.
- If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
- Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
- If your original place of purchase cannot be contacted, please contact Laser with a description of the fault.
- To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
- Phone: (02) 9870 335
- Email: support@laserco.com.au
- Online: www.laserco.net/support/warranty and follow the website instructions.
- Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia.
- Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you

without the need to return the product.

- If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment.
- If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
- Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.
- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.
- You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.
- You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more helpful guides visit us at

LASER

www.youtube.com/LasercoAu www.laserco.com.au



Documents / Resources

The image shows the front cover of a blue instruction manual. At the top, the word "LASER" is printed in white. Below it, "Instruction Manual" is written in a smaller font. In the center is a white line drawing of a slim, rectangular speaker. At the bottom, the text "Laser Pulse Slim Bluetooth Speaker" and "SPK-B60-040" is printed in white.	<p>Laser SPK-B60-040 Pulse Slim Bluetooth Speaker [pdf] Instruction Manual SPK-B60-040, Pulse Slim Speaker, Bluetooth Speaker</p>
--	---

References

- [🔗 Laser: The Ultimate Tech Hub for Home Entertainment, Audio, Smart Home & More](#)
- [🌐 Warranty](#)