

LazeYard HO-S-001 Rotating Bookshelf



# LazeYard HO-S-001 Rotating Bookshelf Instruction Manual

[Home](#) » [LazeYard](#) » LazeYard HO-S-001 Rotating Bookshelf Instruction Manual 

## Contents

- [1 LazeYard HO-S-001 Rotating Bookshelf](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 ASSEMBLY PARTS LIST PIATE](#)
- [5 Parts](#)
- [6 Product Structure Diagram](#)
- [7 Installation steps](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

# LazeYard

**LazeYard HO-S-001 Rotating Bookshelf**



### **Product Specifications:**

- Weight: 105g
- Dimensions: 210×148.5mm

### **Product Information**

The LazeYard Rotating Bookshelf is designed to help you decorate your home in a simple yet beautiful way. The model number is HO-S-001. It comes with a variety of circular plates and shelves to create a unique storage solution for your books or decorative items.

### **Product Usage Instructions**

#### **Before Installation:**

1. Check that all accessories and plates are complete and intact.
2. Refer to the accessories table for details.

#### **Installation Steps:**

1. Connect plate and plate together.
2. Put the eccentric wheel into the hole of the plate and connect it with a screw.
3. Connect the plates with screws and install the baffle of the bookshelf into each layer.
4. Repeat the installation process for all sides of the bookshelf.

#### **Additional Steps:**

Follow the numbered markings on the plates for correct installation. Stick the screw hole with a C sticker for a complete look.

#### **FAQ:**

**1. Q: What is the warranty period for the LazeYard Rotating Bookshelf?**

A: The product comes with a 90-day warranty starting from the original purchase date, covering manufacturer-related issues. For support, contact Customer Service at [Support@lazeyard.com](mailto:Support@lazeyard.com) with your order details.

**2. Q: Where can I find more information about the product?**

A: For further inquiries or assistance, you can reach out to the manufacturer, SHENZHEN YONGCHUANGCHENG TECHNOLOGY CO., LTD., based in Shenzhen, China.

Hello, thank you for purchasing LazeYard rotary bookshelf. Please read this user manual carefully and keep it properly for future reference. If you need any help, please contact the store and provide your Amazon order number.

#### **NOTE**

Please carefully check whether the accessories and plates are complete and intact after receiving the products. Please refer to the accessories table for details.

During the installation, please follow the instructions to avoid hole bursting caused by repeated installation. The plate is marked with a number. Please install the number corresponding to the plate in the instruction manual..

**After-sales e-mail:** [Support@lazeyard.com](mailto:Support@lazeyard.com)



#### **Manufacturer Name:**

SHENZHEN YONGCHUANGCHENG TECHNOLOGY CO., LTD.

#### **Address:**

6F, MAOCHENG BLDG, XICHENG INDUSTRIAL AREA, XIXIANG, BAO'AN DIST, SHENZHEN, CHINA, 518126  
Made in China









- **STEP17** Stick the screw hole with C sticker to obtain a complete and beautiful product.











### **GUARANTEE**

We offers a 90-day warranty that begins on the date of the original purchase and applies to problems caused by the manufacturer. For questions, assistance, or support, please contact the Customer Service by e-mail to [Support@lazeyard.com](mailto:Support@lazeyard.com) with your order number and details. We will send you further information about the solution.


### **ASSEMBLY PARTS LIST PIATE**

① plate  4PCS	② plate  4PCS	③ Shelf baffle  16PCS
④ Circular plate  1pcs	⑤ Circular plate  1pcs	⑥ Circular plate  1pcs
⑦ Circular plate  2pcs	⑧ Circular plate  1pcs	


## Parts


A M5 42  16 PCS	B Ø15 10  16 PCS	C Ø17  WHITE 16 PCS	D M5 40  64 PCS
E M6*12  8 PCS	F  Rotating component: 1pcs	G Ø30  Non-slip mat: 4PCS	 Screwdriver: 1PCS

## Product Structure Diagram





- **STEP16** Install G non-slip mat on ④ plate







- **STEP14** Connect the four corners of F Rotating component to ④ plate with E screw




- **STEP15** Connect ④ plate with ⑤ plate of STEP13, and align the locking screws by rotating ④ plate to the hole position




## Installation steps



- **STEP1** Connect ①plate and ② plate together







- **STEP2** Put B eccentric wheel into the hole of ① and ② plate, then drill A screw into ⑥ plate, and connect B eccentric wheel with its head and lock eccentric wheel





A M5*42	B Ø15*10
	
4 PCS	4 PCS

- **STEP3** Connect ⑦ plate to the upper part of STEP2 with D screw, Put D screw on the upper right corner





- **STEP4** Install the baffle of ③ bookshelf into this layer, and repeatedly install D Screw on the the upper right corner of 4 sides baffle








- **STEP13** Install the baffle of ③ bookshelf into this layer, and repeatedly install the baffle of 4 sides





- **STEP11** Connect ①plate and ② plate, and connect them into ⑦ through STEP2





<p>A M5*42</p>  <p>4 PCS</p>	<p>B Ø15*10</p>  <p>4 PCS</p>
---	--

- **STEP12** Connect ⑤ plate with D screw in STEP 11









- **STEP5** Connect ① plate and ② plate, and connect them into ⑦ plate through STEP2




- **STEP6** Connect ⑧ plate to STEP5 with D screw





- **STEP7** Install the baffle of ③ bookshelf into this layer, and repeatedly install the baffle of 4 sides






- **STEP8** Connect ① plate and ② plate, and connect them to ⑧ plate through STEP2



<p>A M5*42</p>  <p>4 PCS</p>	<p>B Ø15*10</p>  <p>4 PCS</p>
---	--



- **STEP9** Connect ⑦ plate to STEP8 with D screw



<p>C Ø6*40</p>  <p>2 PCS</p>	<p>D M5*40</p>  <p>4 PCS</p>
---	---

- **STEP10** Install the baffle of ③ bookshelf into this layer, and repeatedly install the baffle of 4 sides





## Documents / Resources

	<a href="#">LazeYard HO-S-001 Rotating Bookshelf</a> [pdf] Instruction Manual HO-S-001 Rotating Bookshelf, HO-S-001, Rotating Bookshelf, Bookshelf
--	---

## References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.