

LeapFrog Build-a-Slice Pizza Cart Instruction Manual

Home » LeapFrog » LeapFrog Build-a-Slice Pizza Cart Instruction Manual


LeapFrog Build-a-Slice Pizza Cart

Contents

- 1 INTRODUCTION
- **2 GETTING STARTED**
- 3 Documents /
- Resources
- **4 Related Posts**

INTRODUCTION

Thank you for purchasing the Build-a-Slice Pizza Cart™! Explore counting, colors and even some Italian phrases while making, baking and delivering your own pretend pizzas! Ding! Ding! Order up!



INCLUDED IN THE PACKAGE



1 Build-a-Slice Pizza Cart™

1 handle

- 1 canopy
- 1 menu board
- 1 chimney
- 4 pizza slices
- 6 pizza toppings
- 10 one-dollar bills
- 5 coins
- 1 plate

- 1 pizza cutter
- 1 cheese shaker
- 1 pizza paddle
- 1 pizza box
- · Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

NOTE:

After removing from packaging, wipe all the included pieces using a slightly damp cloth. Wash the Pizza Cutter, Plate and the Oven Paddle thoroughly before and after use. To avoid damaging the electronics, do not submerge the items in water or expose them to excessive moisture.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

- 1. Make sure the unit is turned Off.
- 2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- 4. Install 3 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
- 5. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- · Remove exhausted batteries from the toy.

• Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

ASSEMBLY

With the Build-a-Slice Pizza Carts safety comes first. To ensure your child's safety, adult assembly is required.

- 1. Insert the Chimney and Menu Board firmly into the top of the Pizza Cart
- 2. Attach the Canopy onto the Chimney and Menu Board.
- 3. Insert the Handle into the top of the Pizza Cart.

LABEL APPLICATION

Please securely adhere the labels to the cart as indicated below.

Match the label numbers to the corresponding numbered spots on the cart. Note: Two spots on the Canopy will not receive labels. They are intended to remain green.

Documents / Resources



<u>LeapFrog Build-a-Slice Pizza Cart</u> [pdf] Instruction Manual Build-a-Slice Pizza Cart, Slice Pizza Cart, Pizza Cart, Cart

Manuals+,