


Led2 EASY-R Recessed LED Lamp Instruction Manual

[Home](#) » [Led2](#) » Led2 EASY-R Recessed LED Lamp Instruction Manual 

Led2 EASY-R Recessed LED Lamp



Contents

1 Instructions for Use

2 CONNECTION – DIMMABLE VERSION – OPTIONAL

3 Documents / Resources






3.1 References

4 Related Posts

Instructions for Use





The installation may only be carried out by a technician



CAUTION!

Turn off the main power before proceeding with the installation in order to prevent possible shock. The installation may only be carried out by a technician or a qualified person. If the lamp has a lampshade/diffuser, handle it carefully as it is fragile. With an integrated LED light source, only a technician or a qualified person can make the replacement. The manufacturer is not responsible for the incorrect use and assembly of its products.




CONNECTION – DIMMABLE VERSION – OPTIONAL

1

PUSH DIM


220-240 V 50/60 Hz



2

DALI/PUSH DIM


220-240 V 50/60 Hz




3

DALI DIM

220-240 V 50/60 Hz





CAUTION!

Turn off the main power before proceeding with the installation in order to prevent possible shock. The installation may only be carried out by a technician or a qualified person. If the lamp has a lampshade/diffuser, handle it carefully as it is fragile. With an integrated LED light source, only a technician or a qualified person can make the replacement. The manufacturer is not responsible for the incorrect use and assembly of its products.



Documents / Resources

	<p>Led2 EASY-R Recessed LED Lamp [pdf] Instruction Manual</p> <p>EASY-R Recessed LED Lamp, EASY-R, Recessed LED Lamp, LED Lamp, Lamp</p>
--	--

References

-  [uvod - architectural lighting](#)

Manuals+.