


# **LEDLENSER H15R Core Rechargeable LED Headlamp User Guide**

Home » LEDLenser » LEDLENSER H15R Core Rechargeable LED Headlamp User Guide 🖔




### H15R Core



## H15R Work






Low Power

## Dimming

Off




Mid Power


(Runtime>8h)


Off


## **Transportation Lock**
















Ledlenser GmbH & Co. KG Kronenstrasse 5-7 • 42699 Solingen • Germany Phone +49 212/5948-0 Fax +49 212/5948-200 info@ledlenser.com



H15R\_V.02 2021.07.07 1J12A0445



ai16323586959\_1J12A0445\_H15R\_QUG\_202100909.pdf 2 2021/9/23 8:58:21

#### Contents

- 1 Documents / Resources
- **2 Related Posts**

### **Documents / Resources**



<u>LEDLENSER H15R Core Rechargeable LED Headlamp</u> [pdf] User Guide H15R, Core Rechargeable LED Headlamp, H15R Core Rechargeable LED Headlamp, Rechargeable LED Headlamp, LED Headlamp, Headlamp

Manuals+,