



# LEDLENSER L7 Lightweight LED Torch Instruction Manual

[Home](#) » [LEDLenser](#) » LEDLENSER L7 Lightweight LED Torch Instruction Manual 

## LEDLENSER L7 Lightweight LED Torch




## Contents

- 1 Thank you
- 2 Battery Instillation
- 3 Item
- 4 Turning the lamp ON and OFF
- 5 Focusing system
- 6 Replacing the batteries
- 7 Batteries
- 8 Accessories
- 9 WARNING
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts

## Thank you

Thank you for choosing one of our products.  
To familiarize yourself with this product, please read the following instructions.

## Battery Instillation



## Item

### LED LENSER

7058 Led Lenser L7 Test it gift box  
7108 Led Lenser L7 Gift box  
7008 Led Lenser L7 Blister

**Version:** 2.0

### Battery:

3×AAA/ LR03/ Micro (1.5V DC) (Item No. 7721)

## Turning the lamp ON and OFF

To switch the flashlight ON and OFF, push the button at the end of the flashlight.  
You can also use the switch as a pushbutton. For this press the button and release it after that.

## Focusing system

This lamp is focusable. To adjust the beam to suit your application, simply twist the head of the flashlight.

## Replacing the batteries

Please turn off the light before replacing batteries. To replace the batteries, please unscrew the cap at the end of the lamp. Take out the used (discharged) batteries and dispose of them properly. Always change all batteries at the same time. Use the plus/minus markings on the inside of the battery housing as a guide for inserting the batteries correctly. Close the lamp by screwing the end cap back in place.

**Important** – when inserting new batteries, follow the polarity marks (+) and (-) that are marked on the battery housing. If inserted incorrectly, battery damage could occur which could cause an explosion. To prevent the battery-box from short circuiting/exploding, keep it away from moisture and metal substances.

## Batteries

Never try to recharge batteries or use fresh and used batteries together. Do not use high current batteries or accumulators as they are not compatible with this lamp. If you intend to not use the lamp for a long period of time, take the battery out to prevent it from leaking and damaging the lamp. Discharged batteries should also be removed. Used batteries and accumulators are hazardous waste and must be disposed of according to government regulations.

## Accessories

The enclosed lanyard can be fastened at the end of the flashlight.


## WARNING

Do not shine the light directly in someone's eyes. If the light beam does shine directly in your eye, look away immediately. Do not use any magnifying instruments with this lamp that could concentrate the light beam.

In case of commercial usage, the user of the lamp must be instructed according to the national regulations for health and safety and the rules of practice.



## Documents / Resources



[LEDLENSER L7 Lightweight LED Torch](#) [pdf] Instruction Manual  
L7, L7 Lightweight LED Torch, Lightweight LED Torch, LED Torch, Torch

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.