



LEDLyskilder R1-1 One Key RF Remote Controller User Manual

[Home](#) » [LEDLyskilder](#) » LEDLyskilder R1-1 One Key RF Remote Controller User Manual 

Contents

- [1 LEDLyskilder R1-1 One Key RF Remote Controller](#)
- [2 Features](#)
- [3 Technical Parameters](#)
- [4 Mechanical Structures and Installations](#)
- [5 Match Remote Control](#)
- [6 Safety information](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



LEDLyskilder R1-1 One Key RF Remote Controller



Features

- Apply to single color LED controller.
- Each remote can match one or more receivers.
- CR2032 battery powered.

- Operate with LED indicator light.
- Magnet on the back which can be easily stuck on any metal surface.

Technical Parameters


Input and Output	
Output signal	RF(2.4GHz)
Working voltage	3VDC(CR2032)
Working current	< 5mA
Standby current	< 2μA
Standby time	2 years
Remote distance	30m(Barrier-free space)

Warranty	
Warranty	5 years

Safety and EMC	
EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
Safety standard(LVD)	EN 62368-1:2020+A11:2020
Radio Equipment(RED)	ETSI EN 300 328 V2.2.2
Certification	CE,EMC,LVD,RED

Environment	
Operation temperature	Ta: -30℃ ~ +55℃
IP rating	IP20

Mechanical Structures and Installations



To fix the remote, three options are offered for selection:

- Option 1: stuck on any metal surfaces directly.
- Option 2: fix it on the wall with two screws.
- Option 3: adhere it to the wall with a paster.

Match Remote Control

End users can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

- **Match:**

Short press match key, immediately press on/off key on the remote. The LED indicator fast flash a few times means match is successful.

- **Delete:**

Press and hold match key for 5s to delete all match, The LED indicator fast flash a few times means all matched remotes were deleted.

Use Power Restart

- **Match:**

Switch off the power, then switch on power, repeat again. Immediately short press on/off key 3 times on the remote. The light blinks 3 times means match is successful.



- **Delete:**

Switch off the power, then switch on power, repeat again. Immediately short press on/off key 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

Safety information

1. Read all instructions carefully before you begin this installation.
2. When installing battery, pay attention to the battery's positive and negative polarity. A long time without the remote control, remove the battery. When remote distance becomes smaller and insensitive, replace the battery.
3. If no response from the receiver, please re-match the remote.
4. Gently handle remote, beware of falling.
5. For indoor and dry location use only.

Documents / Resources

	LEDLyskilder R1-1 One Key RF Remote Controller [pdf] User Manual R1-1, One Key RF Remote Controller, R1-1 One Key RF Remote Controller, RF Remote Controller, Controller
	LEDLyskilder R1-1 One-Key RF Remote Controller [pdf] User Manual R1-1, One-Key RF Remote Controller, R1-1 One-Key RF Remote Controller