



# LEDOLUX ORBIT LED Lamp Instruction Manual

[Home](#) » [LEDOLUX](#) » LEDOLUX ORBIT LED Lamp Instruction Manual 

## Contents



- [1 LEDOLUX ORBIT LED Lamp](#)
- [2 PRODUCT OVERVIEW](#)
- [3 NOTE](#)
- [4 APPLICATION](#)
- [5 NOT INCLUDED](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



## LEDOLUX ORBIT LED Lamp



## PRODUCT OVERVIEW



	Ø	H	Waga
100W	340mm	200mm	4.5kg
150W	340mm	200mm	5.0kg
200W	340mm	200mm	5.0kg
240W	340mm	200mm	5.5kg

NOMINAL VOLTAGE

**205 - 260V ~**

FREQUENCY

**50 / 60Hz**

COLOUR TEMPERATURE

**4000K / 5000K**

LUMINOUS EFFICACY

**200lm/W**

BEAM ANGLE

**120° / 90° / 60°**

OPERATING TEMPERATURE


**-25°C ÷ +65°C**

MOUNTING HEIGHT

## NOTE

- The terminal block is not supplied. Installation must be performed by a qualified person. In case of doubts as to the installation or use of the LED luminaire, consult the manufacturer.
- Replace the luminaire after a failure. Self-repair shall void the warranty.
- This product contains a light source with energy efficiency class A.
- Keep the luminaire in a cool, dry, and clean environment. Keep away from water and fire
- Make sure you disconnect the power supply before installation. Turn on the power after connecting and securing all luminaires in the circuit.
- The light source used in this luminaire should only be replaced by the manufacturer or their service representative, or a similarly qualified person
- Protect your eyes, and avoid looking at the light for a long period of time.
- Dirtiness that settles down on the luminaire due to normal operation shall be cleaned with a damp cloth.
- Do not use invasive cleaners or cleaning methods.

## APPLICATION



- Industrial facilities
- Warehouses
- Technical rooms
- Sport facilities

Ledolux Poland Sp. z o.o.

E-mail: [info@ledolux.pl](mailto:info@ledolux.pl)

Tel: +48 696 966 622

Data: 12.12.2022

We reserve the right to make design changes to luminaires.


**Make sure you disconnect the power supply before installation**




1. Fix the mounting bracket to the luminaire (hook M10, 10Nm).




2. Drill a hole in the ceiling and install the hook.




3. Hang luminaire




4. Connect the luminaire according to the wire markings.



5. Keep it watertight while connecting it.



6. Drill a hole in the ceiling, install screws.



7. Fix the mounting bracket to the luminaire using a hex wrench (4mm, 3Nm). Adjust the angle of tilt of the luminaire and lock the holder with a hex key (6mm, 5Nm). Attach the luminaire to the wall/ construction.

8. Connect the luminaire according to the wire markings. Keep it watertight while connecting it




## NOT INCLUDED

### Connecting the power cable




### Connecting the dimming cable



When no dimming, secure dimming cables – separate and isolate each one.

## Documents / Resources



[LEDOLUX ORBIT LED Lamp](#) [pdf] Instruction Manual  
ORBIT, ORBIT LED Lamp, LED Lamp, Lamp

