



# IEDYi Lighting S1-B Bluetooth and RF AC Triac Dimmer Instruction Manual

[Home](#) » [LEDYI Lighting](#) » IEDYi Lighting S1-B Bluetooth and RF AC Triac Dimmer Instruction Manual 

## Contents

- 1 IEDYi Lighting S1-B Bluetooth and RF AC Triac Dimmer
- 2 Bluetooth & RF AC Triac Dimmer
- 3 Features
- 4 Technical Parameters
- 5 Mechanical Structures and Installations
- 6 System wiring
- 7 Wiring diagram
- 8 Compatible Load Types
- 9 Leading edge or trailing edge dimming setting
- 10 Min brightness setting
- 11 Tuya APP network connection and operation
- 12 S1-B(WB) match RF remote control (Optional)
  - 12.1 Use the S1-B(WB)'s Match key
  - 12.2 Use Power Restart
  - 12.3 Use Power Restart
- 13 Documents / Resources
- 14 Related Posts



**IEDYi Lighting S1-B Bluetooth and RF AC Triac Dimmer**



## Bluetooth & RF AC Triac Dimmer

**Model No.: S1-B(WB)**

Tuya APP cloud control/RF dimming/Push Dim/Leading edge or trailing edge/Wall junction box mounting

### Features

- Bluetooth + RF + Push AC phase-cut dimmer, 1 channel output.
- To dim and switch single color dimmable LED lamps, traditional incandescent and halogen lights.
- Tuya APP cloud control, support on/off, brightness adjust, delay turn on/off light, timer run, scene and music play function.
- 256 levels 0-100% dimming smoothly without any ash.
- Leading edge dimming or trailing edge dimming set by dip switch.
- Min brightness can be set by key.
- Light on/off fade time 3s selectable.
- Compatibility with RF 2.4G single zone or multiple zone dimming remote control.
- Each S1-B(WB) controller can also work as Bluetooth-RF converter, then use Tuya APP to control one or more RF dimming LED controller or driver synchronously.
- Connect with external push switch to achieve on/off and 0-100% dimming function.
- Easy to be placed in standard wall junction box behind a push switch.
- Over-heat / Over-load protection, recover automatically.

### Technical Parameters

## Input and Output

Input voltage	AC100-240V
Output voltage	AC100-240V
Output current	Max 1.5A
Output power	150-360W

## Environment

Operation temperature	Ta: -30 OC ~ +55 OC
Case temperature (Max.)	T c: +85OC
IP rating	IP20

## Safety and EMC

EMC standard (EMC)

ETSI EN 301 489-1 V2.2.3  
ETSI EN 301 489-17 V3.2.4

Safety standard(LVD)

EN 62368-1:2020+A11:2020

Radio Equipment(RED)

ETSI EN 300 328 V2.2.2



Certification

CE,EMC,LVD,RED


Dimming data	
Input signal	Tuya APP + RF + Push Dim
RF Control distance	30m(Barrier-free space)
Dimming level	256 levels
Dimming range	0 -100%

Weight	Net weight	Gross weight
Weight unit(g)	0.048kg	0.061kg


## Mechanical Structures and Installations



Typical Wall Junction Box Mounting





## System wiring



### Note:

1. The above distance is measured in spacious (no obstacle) environment, Please refer to the actual test distance before installation.
2. Users must use the Tuya Bluetooth gateway to realize remote control and voice control.

## Wiring diagram




**Note:** When calculating the maximum number of load lamps or drivers, the input power or input current parameters of a single lamp or driver must be used, the output power parameters can not be used. In addition, the maximum surge current of the dimmer is 65A, the sum of surge current of multiple dimmable LED drivers should not exceed 2 times. otherwise, the product will be overloaded and damaged.

## Compatible Load Types

Load Type	Maximum Load	Remarks
Dimmable LED lamps	200W @ 220V 100W @ 110V	Due to variety of LED lamp designs, maximum number of LED lamps is further dependent on power factor result when connected to dimmer.
Triac Dimmable LED drivers	200W @ 220V 100W @ 110V	Maximum permitted number of drivers is 200W divided by driver nameplate power rating, and make sure the surge current is no more than 2 times 65A.
Incandescent lighting, HV Halogen lamps	400W @ 220V 200W @ 110V	

## Leading edge or trailing edge dimming setting


Select leading edge(forward-phase) dimmer or trailing edge(reverse-phase) dimmer according to dimmable LED light or driver.




Reverse-phase

Forward-phase

Forward-phase control dimmer(TRIAC)



Reverse-phase control dimmer




Caution: before power on, you must confirm the selection of dip switch.

### Min brightness setting

Long press Min set key for 10s, the light blink 2 times, ready for min brightness set, then short press Min set key 1-6 times, to get 6 min brightness: 5%, 10%, 15%, 20%, 25% or 30%, the light will output the current min brightness immediately, Wait 8s, quit min brightness set automatically, the light will return output 100% brightness.



## Tuya APP network connection and operation



Press and hold Match/Set key for 5s, or push twice Match/Set key fastly, Clear previous network connection, enter config mode. the blue LED indicator fast flash.

If Tuya APP network connection succeed, the blue LED indicator will stop flash, and in Tuya APP, you can find BT-DIM device.

**Tuya APP interface operation:** Touch brightness slide to adjust brightness.

### S1-B(WB) match RF remote control (Optional)

End user can choose the suitable match/delete ways. Two options are offered for selection:

#### Use the S1-B(WB)'s Match key

**Match:** Short press match key of S1-B(WB), immediately press on/off key (single zone remote) or zone key (multiple zone remote) on the remote.

**Delete:** Press and hold match key of S1-B(WB) for 15s to delete all match, The light blinks 5 times means all matched remotes were deleted.

#### Use Power Restart

**Match:** Switch off the power of S1-B(WB), then switch on power, repeat again, Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote.

The light blinks 3 times means match is successful.

#### **Delete:**

Switch off the power of S1-B(WB), then switch on power, repeat again, Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote.

The light blinks 5 times means all matched remotes were deleted.

## **S1-B(WB) work as Bluetooth-RF converter to match other RF dimming LED controller or driver**

End user can choose the suitable match/delete ways. Two options are offered for selection:

### **Use the controller's Match key**

- Match: Short press match key of the controller, immediately press on/off key on the Tuya APP. The LED indicator fast flash a few times means match is successful.
- Delete: Press and hold match key of the controller for 5s, The LED indicator fast flash a few times means match was deleted.

### **Use Power Restart**

#### **Match:**

Switch off the power of the controller, then switch on power, repeat again, Immediately short press on/off key 3 times on the Tuya APP. The light blinks 3 times means match is successful.

#### **Delete:**

Switch off the power of the controller, then switch on power, repeat again, Immediately short press on/off key 5 times on the Tuya APP. The light blinks 5 times means match was deleted.


### **AC Push Dim Function (Optional)**

- Short press: Turn on or off light.
- Long press (1-6s):
- Press and hold to step-less dimming, With every other long press, the light level goes to the opposite direction.
- Dimming memory: Light returns to the previous dimming level when switched off and on again, even at power failure.

### **Light on/off fade time**

Switch off the power, then switch on power, repeat again. Immediately short press match key 3 times, the light on/off time will change between 3s and 0.5s.

### **Documents / Resources**



[IEDYi Lighting S1-B Bluetooth and RF AC Triac Dimmer](#) [pdf] Instruction Manual  
S1-B Bluetooth and RF AC Triac Dimmer, S1-B, Bluetooth and RF AC Triac Dimmer