



legrand 4 149 49 Energy Management Multi Support Web Server Instructions

[Home](#) » [Legrand](#) » legrand 4 149 49 Energy Management Multi Support Web Server Instructions 




legrand 4 149 49 Energy Management Multi Support Web Server



Contents



- [1 What is in the Box](#)
- [2 Description](#)
- [3 Wiring diagram](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)


What is in the Box




The instructions for installation and use must be strictly observed in order to avoid the risk of electric shock or fire.

Description




U	 230 V~ / 12 V , 3 A
P	10,2 W
	Ethernet RJ45; 10/100/1000Mb
	192.168.1.100
	255.255.255.0
	192.168.1.1
PIN	99999
PUK	00000 9999 00000
	(-20°C) – (+60°C)


		Green	Device powered
		Orange	Device off/suspended
		Red	HDD activity




Power input connector (Power supplier included)

Wiring diagram





Parts not included



= 0 374 39




M4 x 14 mm (max.)

Complete documentation is available at:



Documents / Resources



[legrand 4 149 49 Energy Management Multi Support Web Server](#) [pdf] Instructions
4 149 49 Energy Management Multi Support Web Server, 4 149 49, Energy Management Multi
Support Web Server, Support Web Server

References

- [Welcome to Legrand - Legrand](#)
- [e-catalogue © Legrand](#)

-  [Catalogue pro | Legrand](#)

Manuals+