

legrand LE12093AC Arteor with Netatmo Connected Wired Light Switch Instruction Manual

<u>Home</u> » <u>Legrand</u> » legrand LE12093AC Arteor with Netatmo Connected Wired Light Switch Instruction Manual



Contents

- 1 legrand LE12093AC Arteor with Netatmo Connected Wired Light Switch
- 2 Pack contents
- 3 Characteristics
- 4 Before you start: wiring precautions
- **5 Safety instructions**
- 6 Documents / Resources
 - **6.1 References**




legrand LE12093AC Arteor with Netatmo Connected Wired Light Switch




This product is a connected accessory that requires you to buy and install the Arteor with Netatmo connected starter pack first.

Pack contents



• Connected switch with neutral (with dimmer option)



Leave home/back home general control

Characteristics

In default operating mode (on/off), this switch works with the following bulbs:

+ 45° C + 5° C			LED		₽ , <u>↑</u>
110-240 VAC 50/60 Hz	2 x 1.5 mm ² 1 x 2.5 mm ²	.☆-	□ ZI⊗	□ ZI⊗	⊒ ZI⊗
240 VAC	Max.	150 W	^(*) 150 VA	150 VA	150 VA
110 VAC	Max.	75 W	^(*) 75 VA	75 VA	75 VA


- Or 15 bulbs max. For a good light comfort, it is recommended to use bulbs of the same type and the same manufacturer.
- In dimmer option operating mode (which can be activated via the App), this switch functions only with dimmable bulbs (identifiable by the logo on packaging).



Before you start: wiring precautions

• Do not use: two connected switches to control the same lighting point.

If you plan to install a two-way light switch, read the following precautions:




- Wireless controls for all control points (not included in this pack)
- Mechanical push button (not included in this pack)

Tip if replacing a two-way switch using a wireless control:

old flush-mounted switch replaced by the wireless control.


• Use a connector to connect live wire and traveller wires 1 and 2.






- 1. Switch OFF the power at the main circuit breaker
- 2. Make sure that the power is OFF before continuing with the installation.


Install the connected switch



- 1. Remove the existing switch
- 2. Wire the connected switch



3. Wire the connected switch



The connected switch with neutral (with dimmer option) works with standard or dimmable bulbs including LED. LED dimmable bulbs are mandatory for optimal dimmer usage.



To add a connected product to your connected installation, you should follow the instructions:

- in the Legrand Home + Control application (Settings/Add a new product section)
- or consult the user manual on legrand.fr
- www.legrand.fr/reference/574341

LEGRAND - Pro and Consumer Service - BP 30076 87002 LIMOGES CEDEX FRANCE • www.legrand.com

Safety instructions

This product should be installed in compliance with installation rules, preferably by a qualified electrician. Incorrect installation and/or incorrect use can lead to risk of electric shock or fire. Before carrying out the installation, read the instructions and take account of the product's specific mounting location. Do not open up, dismantle, alter or modify the device except where specifically required to do so by the instructions. All Legrand products must be opened and repaired exclusively by personnel trained and approved by Legrand. Any unauthorised opening or repair completely cancels all liabilities and the rights to replacement and guarantees. Use only Legrand brand accessories.

SIMPLIFIED EU DECLARATION OF CONFORMITY

The undersigned,

Legrand

declares that the radio-electric equipment referred to in these instructions complies with directive 2014/53/EU.

Documents / Resources



<u>legrand LE12093AC Arteor with Netatmo Connected Wired Light Switch</u> [pdf] Instruction M anual

LE12093AC Arteor with Netatmo Connected Wired Light Switch, LE12093AC, Arteor with Netat mo Connected Wired Light Switch, Netatmo Connected Wired Light Switch, Connected Wired Light Switch, Wired Light Switch, Switch, Switch

References

- Legrand Spécialiste des infrastructures électriques et numériques du bâtiment
- La Welcome to Legrand Legrand
- \$\frac{\textbf{\Pi}}{\text{RAC}}\text{sultats de votre recherche particulier | Legrand

Manuals+,