

Lemokey X3 Mechanical Keyboard User Manual

Home » Lemokey » Lemokey X3 Mechanical Keyboard User Manual

Contents

- 1 Lemokey X3 Mechanical
- **Keyboard**
- 2 IN THE BOX
- 3 Quick Start Guide
- **4 Adjust The Backlight Brightness**
- **5 Factory Reset**
- **6 SPECIFICATIONS**
- **7 OVERVIEW**
- **8 DEFAULT KEY LAYOUT**
- **9 KEY DESCRIPTION**
- **10 Safety Precaution**
- 11 Documents / Resources
 - 11.1 References



Lemokey X3 Mechanical Keyboard






IN THE BOX

- Lemokey X3 Mechanical Keyboard x 1
- Type-C Cable × 1
- Keycap-Switch Puller × 1
- Extra Keycaps Set x 1
- Manual x 1

Quick Start Guide

• The keyboard's default layout is configured for Windows. To use it with MacOS, please remap it using VIA.

Windows




- The VIA Key Remapping Software
- Please visit us via.app to use the online
- VIA software to remap the keys.
- If the VIA cannot recognize your keyboard,
- please reach our support to get the instruction.



- The online VIA software can only run on the latest version of Chrome, Edge, and Opera browsers.
- VIA only works when the keyboard is connected by wire to the computer.

The Backlight

• Press FN + Q to change the lighting effect




• Press FN + TAB to turn the backlight on/off



Adjust The Backlight Brightness

• Press FN + W to increase the backlight brightness



• Press FN + S to decrease the backlight brightness



The Key Rollover

Press FN + N to switch between 6-key rollover and N-key rollover

- 6-key rollover: the keyboard can detect up to 6 simultaneous key inputs.
- N-key rollover: The keyboard can detect all key inputs without limiting the number of key presses.
- The keyboard enables N-key rollover by default.




Factory Reset

Troubleshooting? Don't know what's going on with the keyboard?

- 1. Download the right firmware and QMK Toolbox from our website.
- 2. Unplug the power cable and remove the space bar keycap to find the reset button on the PCB.
- 3. Hold the reset key first, then plug in the power cable. Release the reset key, and the keyboard will now enter DFU mode.
- 4. Flash the firmware with the QMK Toolbox.
- 5. Factory reset the keyboard by pressing FN + J + Z (for 4 seconds).

Step by step guide can be found on our website.



SPECIFICATIONS

X3 MECHANICAL KEYBOARD SPECIFICATIONS

· Layout: Full Sized

• Switch type: Mechanical

Width: 137.8 mmLength: 445.7 mm

• Front height: 20.6 mm (without keycaps) 31.8 mm (with keycaps installed)

• Back height: 30 mm (without keycaps) 41.8 mm (with keycaps installed)

• Keyboard feet height: 1.3 mm


• Angle: 4 / 6 / 8.7 degree

OVERVIEW

X3 MECHANICAL KEYBOARD OVERVIEW


- 1. Caps Lock Indicator
- 2. Windows Lock Indicator
- 3. Num Lock Indicator
- 4. Scroll Lock Indicator
- 5. Type-C Port






DEFAULT KEY LAYOUT


• LAYER 0: This is the default layer.



- LWin=Left Windows LAIt=Left Alt RAIt=Right Alt RApp=Right App RCtl=Right Ctrl
- LAYER 1: This layer will be activated when you press the FN/MO(1) key.



• LAYER 2/LAYER 3: This is a blank layer.



KEY DESCRIPTION

Key Description	
Scr-	Screen Brightness Decrease
Scr+	Screen Brightness Increase
BL-	Backlight Decrease
BL+	Backlight Increase
Prvs	Previous
Play	Play/Pause
Next	Next
Mute	Mute
Vol-	Volume Decrease
Vol+	Volume Increase
NKRO	N-key rollover

Key Description		
BL Toggle	Turn Backlight on/off	
BL Cycle	Backlight Cycle	
MO(1)	Layer 1 will be activated when holding this key	
MO(2)	Layer 2 will be activated when holding this key	
MO(3)	Layer 3 will be activated when holding this key	
MO(4)	Layer 4 will be activated when holding this key	

Third-party input tools are not compatible with the keyboard

- Due to compatibility, versions, brands, and drivers of Windows/Android OS, functions of third-party input tools may be affected while using the keyboard.
- Please make sure your operating system and drivers are up to date.

Certain multimedia keys or function keys do not work

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

Safety Precaution

- Keep the product, accessories, and packaging parts out of the reach of children to prevent any accidents and choking hazards.
- Always keep the product dry to avoid corrosion.
- Do not expose the product to extreme temperatures below -10°C (5°F) or above 50°C (131°F) to preserve the lifespan of the keyboard and battery.

Find us at

- https://www.lemokey.com
- Support@lemokey.com







- Designed by Lemokey
- · Made in China

Documents / Resources

∏ Lemokey

Lemokey X3 Mechanical Keyboard [pdf] User Manual X3 Mechanical Keyboard, X3, Mechanical Keyboard, Keyboard

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.