



LEMONLITE Flashlight User Manual

[Home](#) » [LEMONLITE](#) » LEMONLITE Flashlight User Manual 



Lighting Your Way



XHP
USER MANUAL



READ ENTIRE MANUAL BEFORE OPERATION to ensure proper use.

Contents

- 1 WARNING**
- 2 WARRANTY**
- 3 OPERATION**
- 4 CHARGING**
- 5 SPECIFICATION**
- 6 PACKAGE INCLUDES**
- 7 Documents / Resources**
- 8 Related Posts**

WARNING

- Do not shine directly into the eyes.
- Keep out of reach of children or pets.
- Do not short-circuit the charger or the battery.
- Do not use or handle the device while charging.
- Never crush or puncture the battery.
- Never place the battery or device on, or in, heating units.
- Do not dispose of battery or device in a fire.
- Store device in a cool dry area.
- Be sure full charge the light/battery if not use over 3 months.

WARRANTY

LEMONLITE product is covered by a warranty of ONE YEAR commencing at the date of purchasing from an authorized LEMONLITE distributor.

This warranty does not cover caused by deliberate damage, violent impact, unauthorized dismantling.

Warranty service should only be undertaken by LEMONLITE or LEMONLITE Authorized Service Provider, if you attempt to repair or modify LEMONLITE PRODUCT by yourself, it will not be covered by warranty.

Prior to your return, please contact LEMONLITE Authorized Service Provider or LEMONLITE directly at customer service info@lemonlite.net to obtain a Return Authorization Number. All returned products must be packed carefully and enclose with the warranty certificate (Proof of purchase) with instructions for repair.

MORE INFORMATION

For more information about limonite products, please visit: www.lemonlite.net

OPERATION

Press the button once to turn the torch on.

The modes cycle in the following order: high – strobe – COB – off.

Release the light head for a focus or flood beam.

**Battery Indicator:**

The LED indicator on button displays current battery status.

4 Blue LED – (70%-100%)	3 Blue LED – (40%-70%)
2 Blue LED – (15%-40%)	1 Blue LED – (5-15%)

Blue LED Flashing – Less than 5%

When the battery less than 15%, please charge your light timely.



CHARGING

Make sure full charge before the first use.



To charge your torch:

1. Turn off the torch.
2. Connect the torch to your PC via the USB cable or charge it via a wall outlet with a 5V USB adaptor.

Charging indicator:

During charging, the LED indicator on the button shows charging status by Blue flashing/Blue LED.

Charging (Illuminates Blue Flashing)

Full Charged (Illuminates Blue LED)

SPECIFICATION

Max Output	2000 Lumens
LED	XHP 70
Run Time	2 – 14 hours
Mode	High-Low-Strobe
Battery	2 x 26650 Rechargeable Battery
Waterproof Level	IPX5
Weight (w/o battery)	311g
Dimensions	240mm(L) x 53mm(D)

PACKAGE INCLUDES


- 1 x Torch
- 2x 28650 Battery
- 1 x USB Cable
- 1 x Easy to Carry Case
- 1 x User Manual



This important Product Information Guide contains safety, disposal/recycling, and regulatory information. Please read all safety information before using the products and accessories in order to avoid injury. As we constantly evolve and improve LEMONLITE products, specifications may change with little or no notice.

Thanks for choose Lemonlite products.

Documents / Resources

	LEMONLITE Flashlight [pdf] User Manual Flashlight XHP
-------------------------------------------------------------------------------------	--------------------------------------------------------------------------