



Contents [[hide](#)]

- 1 [Lemorele H5 USB KVM USB 3.0 Switch Selector 2 Computers](#)
- 2 [Product Information](#)
- 3 [Product Introduction](#)
- 4 [Preface](#)
- 5 [Product Introduction](#)
- 6 [Specifications](#)
- 7 [Package Contents](#)
- 8 [Connection Diagram](#)
- 9 [Installation and Usage](#)
- 10 [Precautions](#)
- 11 [FAQs and Solutions](#)
- 12 [Documents / Resources](#)
 - 12.1 [References](#)



Lemorele H5 USB KVM USB 3.0 Switch Selector 2 Computers



Product Information

Specifications

- Power Supply: 5V/2A
- System Compatibility: Windows, Mac, Linux, Android

Product Introduction

The USB Switch is a device that allows multiple devices to share USB peripherals, such as keyboards, mice, printers, USB drives, etc. It enables quick switching between devices with simple operations, improving work efficiency. It is plug-and-play, requiring no drivers to be installed; just connect and use.

Preface

Dear Valued Customer, Thank you for purchasing a Lemorele product. To better understand this product, please read this manual carefully before use. We wish you a pleasant experience!

Product Introduction

The USB Switch is a device that allows multiple devices to share USB peripherals, such as keyboards, mice, printers, USB drives, etc. It enables quick switching between

devices with simple operations, improving work efficiency. It is plug-and-play, requiring no drivers to be installed; just connect and use.


Specifications

- Input Interface: USB 3.0 × 2
- Output Interface: USB 3.0 × 3
- Power Supply: 5V/2A
- System Compatibility: Windows, Mac, Linux, Android

Package Contents

USB Switch Host × 1/ USB-A to USB-A Cable × 2/ Charging Cable × 1/ User Manual × 1

Connection Diagram



Installation and Usage

1. Connecting Devices

Use a USB data cable to connect the host interface to the computer's USB port. Plug peripherals (such as keyboard, mouse, printer) into the output ports of the USB Switch. Connect the charging cable to the power supply port.

2. Switching Operation:

Button Switching: Press the physical switch button on the device to select the target host.

Precautions

1. Avoid frequent plugging and unplugging of devices to extend the lifespan of the ports.
2. If peripherals are not recognized after switching, check the data cable connections or reconnect the devices.
3. Some high-power peripherals may require additional power support.

Customer Support

If you need assistance, you can contact us at any time by following these steps:

1. Log into your account and go to "Your Orders."
2. Select "Order Issues" next to the relevant order.
3. Send us a message via "Contact Seller."
4. If you encounter issues while using the product, please contact technical support at support@lemorele.com for further assistance.

FAQs and Solutions

The device is not recognized after switching.

Ensure the data cable is securely connected; if necessary, reconnect the device.

The transfer speed is slow.

Check if the USB port is functioning normally.

The peripheral is not working properly.


Check if the correct port needs to be switched.


Documents / Resources

	<p>Lemorele H5 USB KVM USB 3.0 Switch Selector 2 Computers [pdf] User Manual</p> <p>H5, H5 USB KVM USB 3.0 Switch Selector 2 Computers, H5, USB KVM USB 3.0 Switch Selector 2 Computers, KVM USB 3.0 Switch Selector 2 Computers, USB 3.0 Switch Selector 2 Computers, 3.0 Switch Selector 2 Computers, Switch Selector 2 Computers, Selector 2 Computers, 2 Computers</p>
---	--

References

- [User Manual](#)

 Lemorele

 2 Computers, 3.0 Switch Selector 2 Computers, h5, H5 USB KVM USB 3.0 Switch Selector 2 Computers, KVM USB 3.0 Switch Selector 2 Computers, Lemorele, Selector 2 Computers, Switch Selector 2 Computers, USB 3.0 Switch Selector 2 Computers, USB KVM USB 3.0 Switch Selector 2 Computers

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.