



## **Lenco BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set User Manual**

[Home](#) » [Lenco](#) » Lenco BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set User Manual 

**Lenco BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set**



**Model: BTP-400**

**CAUTION:**

Usage of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## Contents

- 1 PRECAUTIONS BEFORE USE
- 2 INSTALLATION
- 3 BLUETOOTH CONNECTION TWS CONNECTION
- 4 TWS CONNECTION
- 5 BASIC OPERATION
- 6 INTERFACE INSTRUCTIONS
- 7 PRODUCT SPECIFICATION
- 8 FREQUENTLY ASKED QUESTIONS
  - 8.1 Guarantee
  - 8.2 Disclaimer
- 9 Disposal of the Old Device
  - 9.1 CE Marking
  - 9.2 Service
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts

## PRECAUTIONS BEFORE USE

### KEEP THESE INSTRUCTIONS IN MIND:

1. Do not cover or block any ventilation openings. When placing the device on a shelf, leave 5 cm (2") free space around the whole device.
2. Install in accordance with the supplied user manual.
3. Keep the device away from heat sources such as radiators, heaters, stoves, candles and other heat-generating products or naked flame. The device can only be used in moderate climates. Extremely cold or warm environments should be avoided. Working temperature between 0° and 35°C.
4. Avoid using the device near strong magnetic fields.
5. Electrostatic discharge can disturb normal usage of this device. If so, simply reset and restart the device following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.
6. Warning! Never insert an object into the product through the vents or openings. High voltage flows through the product and inserting an object can cause electric shock and/or short circuit internal parts
7. Although this device is manufactured with the utmost care and checked several times before leaving the factory, it is still possible that problems may occur, as with all electrical appliances. If you notice smoke, an excessive build-up of heat or any other unexpected phenomena, you should disconnect the plug from the main power socket immediately.
8. This device must operate on a power source as specified on the specification label. If you are not sure of the type of power supply used in your home, consult your dealer or local power company.
9. Keep away from animals. Some animals enjoy biting on power cords.
10. To clean the device, use a soft dry cloth. Do not use solvents or petrol based fluids. To remove severe stains, you may use a damp cloth with dilute detergent.
11. The supplier is not responsible for damage or lost data caused by malfunction, misuse, modification of the device or battery replacement.
12. Do not interrupt the connection when the device is formatting or transferring files. Otherwise, data may be

corrupted or lost.

13. If the unit has USB playback function, the USB memory stick should be plugged into the unit directly. Don't use an USB extension cable because it can cause interference resulting in failing of data.
14. The rating label has been marked on the bottom or back panel of the device.
15. This device is not intended for use by people (including children) with physical, sensory or mental disabilities, or a lack of experience and knowledge, unless they're under supervision or have received instructions about the correct use of the device by the person who is responsible for their safety.
16. This product is intended for non professional use only and not for commercial or industrial use.
17. Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position vibrations or shocks or by failure to follow any other warning or precaution contained within this user manual will not be covered by warranty.
18. Never remove the casing of this device.
19. Never place this device on other electrical equipment.
20. Do not allow children access to plastic bags.
21. Only use attachments/accessories specified by the manufacturer.
22. Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as the power supply cord or the plug, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.
23. Long exposure to loud sounds from personal music players may lead to temporary or permanent hearing loss.
24. If the product is delivered with power cable or AC power adaptor:
  - If any trouble occur, disconnect the AC power cord and refer servicing to qualified personnel.
  - Don't step on or pinch the power adaptor. Be very careful, particularly near the plugs and the cable's exit point. Do not place heavy items on the power adaptor, which may damage it. Keep the entire device out of children's reach! When playing with the power cable, they can seriously injure themselves.
  - Unplug this device during lightning storms or when unused for a long period.
  - The socket outlet must be installed near the equipment and must be easily accessible.
  - Do not overload ac outlets or extension cords. Overloading can cause fire or electric shock.
  - Devices with class 1 construction should be connected to a main socket outlet with a protective earthed connection.
  - Devices with class 2 construction do not require a earthed connection.
  - Always hold the plug when pulling it out of the main supply socket. Do not pull the power cord. This can cause a short circuit.
  - Do not use a damaged power cord or plug or a loose outlet. Doing so may result in fire or electric shock
25. If the product contains or is delivered with a remote control containing coin/cell batteries:

**Warning:**

  - "Do not ingest battery, Chemical Burn Hazard" or equivalent working.
  - The remote control supplied with] This product contains a coin/button cell battery. If the battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
  - Keep new and used batteries away from children.
  - If the battery compartment does not close securely, stop using the product and keep it away from children.
  - If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
26. Caution about the use of Batteries:
  - Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.


- Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
- Replacement of a battery with an incorrect type that can result in an explosion or the leakage of flammable liquid or gas.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or that leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- Attention should be drawn to the environmental aspects of battery disposal.

## INSTALLATION


- Unpack all parts and remove protective material.
- Do not connect the unit to the mains before checking the mains voltage and before all other connections have been made.

### In the Box:


- USB-A to 2 x micro USB



- User manual



## BLUETOOTH CONNECTION TWS CONNECTION




### Step 1 Power On BASIC OPERATION

Long press master and Slave "O" simultaneously for 2S, you will hear a prompt tone of power on. Then the speakers will be connected automatically with a beep sound and the indicator light of Slave will keep blue, master indicator light will keep flashing.


### Step 2 Choose the device

Find Lenco BTP-400 in your bluetooth list and select it.




### Step 3 Pairing Success

The LED indicators on both speakers will keep blue once bluetooth is paired and a beep sound will be heard. You can play music now.



### TWS CONNECTION




## Master and sub-master

### Operation Instructions

1. Long press master and slave "O" simultaneously for 2S to power on. Then the speakers will be connected automatically with a beep sound and the indicator light of sub-master will keep blue, the master's indicator will continue to blink.

(Please turn off bluetooth on your device before TWS paired)

### BASIC OPERATION



① Power Button/Multi-function Button

- Long press ① for 2s to Power On/ OFF



- Short press ① to play/pause during music playing
- Short press ① on master speaker to answer/end an incoming call
- Short press ① twice on master speaker to reject a call
- Short press ① twice to disconnect bluetooth
- Short press ① three times to disconnect TWS


#### ② ③ Volume Button

- Short press ② to turn the volume up/Long Press to next track
- Short press ③ to turn the volume down/Long press to previous track
- Short press ②③ simultaneously to turn on/off flashing white LED during music playing

**Note:** Both speakers can be controlled mutually after paired.

If you are not able to connect two speakers successfully, long press ②③ simultaneously of each speaker for 3S to connect quickly.

## INTERFACE INSTRUCTIONS



| LED            | Description                               |
|----------------|-------------------------------------------|
| Blue Flashing  | Bluetooth Pairing, Out of bluetooth Range |
| Blue On        | Bluetooth Connected Successfully          |
| Red On         | Charging                                  |
| Red Flashing   | Low Battery                               |
| White Flashing | Music Playing                             |
| LED Off        | Fully Charged, Power Off                  |

It will be powered off automatically if bluetooth is unconnected for more than 10 minutes.

## PRODUCT SPECIFICATION

**Product Name:** Lenco

**Model Name:** BTP-400

**Bluetooth Version:** 5.0

**Battery Capacity:** 1500mAh x 2

**Play Time:** 12~14 hours (50% volume)

**Charging Time:** 2~3 hours

**Driver Units:** 10W x 2

**Charging Current:** 5V 0.8A

**Product Size:** 206.5\*78.5\*78mm

**Product Weight:** 860

## FREQUENTLY ASKED QUESTIONS

**Q:** What kind of charger should we use for the speaker?

**A:** All common USB chargers can be used, while we suggest the ones 5V/2A or above 2A.

**Q:** What if there is noise or discontinuous sound during playing?

**A:** The speaker can be normally used within 10m under no obstruction environment. If it is beyond 10m or with obstruction, there might be noise or discontinuous sound.

**Q:** Why the speaker power off automatically after power on but no Bluetooth disconnection?

**A:** When there is no bluetooth pairing in 10 minutes, the speaker will shut down automatically to reduce power consumption.

**Q:** Why can't the speaker connect once-paired with cellphone?

**A:** First, remove the speaker's paired name from the cellphone's Bluetooth List and then restart pairing.

**Q:** The speaker cannot be started up in a normal situation?

**A:** Please plug in the charger and try in a few minutes or try to long press power button 10-30s to reset.

### Guarantee

Lenco offers service and warranty in accordance to European law, which means that in case of repairs (both during and after the warranty period) you should contact your local dealer.

Important note: It is not possible to send products that need repairs to Lenco directly.

Important note: If this unit is opened or accessed by a non-official service center in any way, the warranty expires.

This device is not suitable for professional use. In case of professional use, all warranty obligations of the manufacturer will be voided.

### Disclaimer

Updates to Firmware and/or hardware components are made regularly.

Therefore some of the instruction, specifications and pictures in this documentation may differ slightly from your particular situation. All items described in this guide for illustration purposes only and may not apply to particular situation. No legal right or entitlements may be obtained from the description made in this manual.

## Disposal of the Old Device



This symbol indicates that the relevant electrical product or battery should not be disposed of as general household waste in Europe. To ensure the correct waste treatment of the product and battery, please dispose them in accordance to any applicable local laws of requirement for disposal of electrical equipment or batteries. In so doing, you will help to conserve natural resources and improve standards of environmental protection in treatment and disposal of electrical waste (Waste Electrical and Electronic Equipment Directive).

## CE Marking

Hereby, Lenco Benelux B.V., Thermiekstraat 1a, 6361 HB Nuth, The Netherlands, declares that this product is in compliance with the essential EU directive requirements.

The declaration of conformity may be consulted via [techdoc@commaxxgroup.com](mailto:techdoc@commaxxgroup.com)



## Service

For more information and helpdesk support, please visit [www.lenco.com](http://www.lenco.com)

Lenco Benelux BV, Thermiekstraat 1a, 6361 HB Nuth, The Netherlands

# Lenco

## Documents / Resources

|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <a href="#">Lenco BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set</a> [pdf] User Manual<br>BTP-400, 2-in-1 Waterproof TWS Speaker, Bluetooth Speaker Set, Speaker Set                                                                                                                                                                                                                                                                                      |
|  | <a href="#">Lenco BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set</a> [pdf] User Manual<br>BTP-400 2-in-1 Waterproof TWS Bluetooth Speaker Set, BTP-400, 2-in-1 Waterproof TWS Bluetooth Speaker Set, Waterproof TWS Bluetooth Speaker Set, TWS Bluetooth Speaker Set, Bluetooth Speaker Set, Speaker Set                                                                                                                                                  |
|  | <a href="#">Lenco BTP-400 2 in 1 Waterproof TWS Bluetooth Speaker Set</a> [pdf] User Manual<br>BTP-400 2 in 1 Waterproof TWS Bluetooth Speaker Set, BTP-400, BTP-400 Bluetooth Speaker, 2 in 1 Waterproof TWS Bluetooth Speaker Set, 2 in 1 Bluetooth Speaker Set, Waterproof TWS Bluetooth Speaker Set, TWS Bluetooth Speaker Set, TWS Bluetooth Speaker, Bluetooth Speaker Set, Bluetooth Speaker, Waterproof Bluetooth Speaker, Waterproof Speaker, Speaker |

## References

-  [Group Publishing](#)
-  [Lenco.com](#) | [Officiële Lenco Webshop](#)
-  [Lenco.com](#) | [Officiële Lenco Webshop](#)

