




## Letsfit Sleep Sound Machine T3 User Manual

[Home](#) » [Support](#) » Letsfit Sleep Sound Machine T3 User Manual 

### Contents

- [1 Letsfit Sleep Sound Machine T3](#)
- [2 Package Contents](#)
- [3 At a Glance](#)
- [4 Getting Started](#)
  - [4.1 Power On / Off](#)
  - [4.2 Choose Your Sound](#)
  - [4.3 Volume Control](#)
  - [4.4 Auto-Off Timer Set](#)
  - [4.5 Night Light](#)
  - [4.6 Colorful Ambient Light](#)
  - [4.7 EQ Set](#)
  - [4.8 Use T3 with Your Headphones](#)
  - [4.9 Restore Factory Defaults](#)
- [5 Specifications](#)
- [6 DOWNLOAD](#)
- [7 Related Posts](#)

**Letsfit Sleep Sound Machine T3**




## USER MANUAL

Thank you for purchasing our product. This manual addresses the safety guidelines, warranty and operating instructions. Please review this manual thoroughly before operating your device.

### Package Contents

- Sleep Sound Machine × 1
- Power Adapter × 1
- User Manual × 1

### At a Glance



- ① White noise sound
- ② Fan sound
- ③ Natural sound & lullaby
- ④ Volume –


- ⑤ Power switch
- ⑥ Volume +
  
- ⑦ Timer
- ⑧ Sound effect
- ⑨ Night light
- ⑩ Speaker
- Power jack
- 3.5mm audio port


## Getting Started

### Power On / Off

#### Note:


The machine does not have a built-in battery. Please connect the machine to a power source using the power adapter provided before use.



Tap the "  " button to turn on / off the machine and it will not affect the use of night light and ambient light.


### Choose Your Sound

#### White noise sound

Tap the "  " button to choose a white noise sound you wish to listen. The machine provides 8 white noise sounds:


- 1) TV white noise
- 2) Radio white noise
- 3) Original mix white noise
- 4) Torrential pink noise
- 5) Pink noise
- 6) Ambient pink noise
- 7) Brown noise
- 8) Soothing brown noise

#### Fan sound

Tap the "  " button to choose a fan sound you wish to listen. The machine provides 8 fan sounds:



- 1) Humidifier fan
- 2) Home fan
- 3) Electric fan
- 4) Cement fan
- 5) Machine fan
- 6) Healing fan
- 7) Big fan
- 8) Clothes dryer



### **Natural sound & lullaby**

Tap the " " button to choose a natural sound or a lullaby you wish to listen. The machine provides 10 natural sounds and 4 lullabies:



- 1) Water stream
- 2) Thunder rain
- 3) Ocean wave
- 4) Seagulls and ocean wave
- 5) Cricket
- 6) Forest bird song
- 7) Brook bird
- 8) Campfire
- 9) Choo choo
- 10) Strong breeze
- 11) Twinkle twinkle little star
- 12) Hush little baby
- 13) Rock-a-bye baby
- 14) Brahms' lullaby

### **Volume Control**

Tap the " " button once to increase the volume by one level. Tap and hold the " " button to increase the volume continuously.

Tap the " " button once to decrease the volume by one level. Tap and hold the " " button to decrease the volume continuously.

### **Auto-Off Timer Set**


When the machine is on, tap the " " button to set the timer for 15/30/60/90/120mins or turn it off. You can also tap and hold the " " button to turn off the timer directly.

### **Note:**

Turn off the timer if you wish to listen to the sounds continuously.

### **Night Light**

Tap the metal speaker grill to turn on / off the night light.

When the night light is on, you can tap and hold the " " button to adjust the brightness

### **Colorful Ambient Light**


Tap the "☀️" button to choose an ambient light (6 colors: red, yellow, blue, pink, aqua, and purple, and a color-changing mode). Tap and hold the "☀️" button to adjust the brightness. Tap the metal speaker grill to turn off the ambient light.

### EQ Set

Tap the "(O)" button to choose a sound effect (4 sound effects for you to choose: pop, rock, jazz, and classical). Tap and hold the "(O)" button to turn off the sound effect function and you will hear a tone.

### Use T3 with Your Headphones

You can play the sounds with your headphones. Plug the 3.5mm audio connector of your headphones into the audio port of the machine.



### Restore Factory Defaults

Tap and hold the "🔌" button for about 5 seconds until you hear a voice prompt "Factory Recovery" and the machine will be turned off.

### Specifications

- Model: T3
- Audio Output: 3W
- Working Voltage: DC 5V / 1A
- Output Connector: 3.5mm audio connector
- Working Temperature: -10°C to 50°C
- Working Humidity: 20% to 90%; non-condensing
- Dimension: 101 x 101 x 51mm

---

### DOWNLOAD

