



# Lexibook ROB50US Powerman Toy Robot User Manual

[Home](#) » [Support](#) » Lexibook ROB50US Powerman Toy Robot User Manual 

## Contents

- [1 Lexibook ROB50US Powerman Toy Robot](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 Dimension](#)
- [7 Usage](#)
- [8 Care and Maintenance](#)
- [9 Troubleshooting](#)
- [10 Pros and Cons](#)
- [11 Warranty](#)
- [12 FAQs](#)
- [13 Video-Lexibook ROB50US Powerman Toy Robot](#)
- [14 Reference Link](#)
  - [14.1 References](#)
- [15 Related Posts](#)



**Lexibook ROB50US Powerman Toy Robot**



**Launch Date:** July 18, 2021

**Price:** \$59.99

## Introduction

The Lexibook ROB50US Powerman Toy Robot is a flexible and interactive friend for kids ages 4 and up that is meant to entertain and teach them. This robot encourages imagination and interest with its bright lights, sounds, and fun activities. Powerman can move in any direction, dance, play music, and even tell old Aesop stories with the help of an easy-to-use remote control. Its games help kids learn about things like animals, numbers, and everyday things. Playing is fun and learning at the same time. Kids can record their words and then hear them played back in Powerman's funny robot voice. The disc-shooting function makes play sessions more exciting and full of action. The non-toxic plastic used to make this robot is strong and will last a long time. Powerman encourages active play with songs that are already loaded and dance moves that are choreographed. The Lexibook ROB50US is a must-have for any child because it is small and light. This smart, playable toy robot is ready to learn and have fun.

## Specifications

- **Model Name:** ROB50US

- **Brand:** Lexibook
- **Material:** Plastic
- **Dimensions (L x W x H):** 8.15" x 5.24" x 14.49"
- **Weight:** 2.1 pounds
- **Recommended Age:** 4 years and above (Manufacturer Minimum Age: 48 months)
- **Power Requirements:**
  - Robot: 5x AA batteries (not included)
  - Remote: 2x AA batteries (not included)
- **Play Location:** Floor
- **Theme:** Robot Toy
- **Outer Material:** Durable, non-toxic plastic
- **Assembly Required:** No

## Package Includes

- 1 Lexibook ROB50US Powerman Toy Robot
- 1 Infrared remote control
- 9 Foam discs for the shooting feature
- 1 Instruction manual

## Features



**MOVES AND  
DANCES**



**TESTS YOUR  
KNOWLEDGE**



**PLAYS MUSIC**



**TELLS STORIES**



**SHOOTS  
FOAM DISCS**



**TELLS JOKE**



- **Interactive Play:** Powerman can be controlled by an IR remote and offers a never-ending stream of games, quizzes, and stories to enjoy.
- **Recording Voice:** You can record and play back messages or funny lines, and Powerman will say them again in his robot voice.
- **Educational Games:** These are games that teach kids while they play. They include knowledge games about numbers, animals, everyday life, and more




- **Programmable Actions:** Kids can set up Powerman to do a series of moves and jobs, which helps them be creative and solve problems.
- There is music built right in. Powerman plays 12 songs that get kids to dance and move.
- **Shooting Foam Discs:** Powerman has a function that lets you shoot discs, which adds another fun fun to playtime with 9 foam discs.
- **Storytelling Mode:** Powerman can read 10 famous Aesop's fables, which helps kids learn language and use their imaginations.
- **Remote Control Usability:** Kids can move Powerman forward, backward, left, and right with the easy-to-use

remote control, which gives them full power over what he does.

- **Build to Last:** Powerman is made from strong, non-toxic materials that will last through hours of play.
- **Effects of Light and Sound :** Powerman has fun sounds and light effects that make playing more fun and engaging.
- **Dancing Choreographies:** Powerman comes with two built-in dance routines that are fun to watch because they mix movement, music, and lights.
- **Educational Riddles:** Powerman asks kids fun riddles that help them learn about different topics and gives them instant feedback on how they did.
- **Learning Themes:** Powerman talks about animals, numbers, everyday life, and other educational themes in a way that makes learning fun and interactive.
- **Simple to Use Router:** The remote control is easy for kids to use, so they can easily control Powerman's actions and moves.
- When you press the record button, Powerman will play back your words in a funny robot voice, which makes the game even more fun.

## Dimension



## Usage

1. Insert 6 AA batteries into the Powerman Robot and the remote control.
2. Use the remote to command movements, play games, or activate features like music or storytelling.
3. To program, press the designated button on the remote, input a sequence, and watch Powerman execute the commands.
4. Load discs into the robot's launcher for action-packed play, and press the shooting button on the remote.
5. Use the recording function to create personalized messages.

## Care and Maintenance

- Wipe the robot with a clean, dry cloth to remove dirt and dust.
- Avoid using water or cleaning agents to prevent damage to electronic components.
- Store Powerman in a dry and safe place when not in use.
- Regularly check and replace batteries to ensure optimal performance.
- Keep the remote control and robot's components away from small children to avoid accidental damage.

## Troubleshooting

1. **Robot not responding to commands:**
  - Ensure the batteries in both the robot and remote are fresh and correctly installed.
  - Check for obstacles between the robot and the remote that may block the signal.
2. **Disc shooter not working:**
  - Confirm that the discs are loaded correctly.
  - Clean the shooter mechanism to remove dust or debris.
3. **Robot stops mid-function:**
  - Turn the robot off and on to reset.
  - Replace the batteries if the issue persists.
4. **Voice recording not playing back:**
  - Check if the recording feature is activated. Re-record and try playing the message again.
5. **Remote control not working:**
  - Make sure the remote is within the effective range of the robot (approximately 5-10 feet).

## Pros and Cons

### Pros

- Engaging in bilingual content enhances language skills.
- Interactive features promote learning through play.
- Fun foam disc shooting adds excitement to playtime.

### Cons

- Batteries are not included, requiring additional purchase.

- Some users may find it challenging to navigate all features initially.

## Warranty

The Lexibook Powerman Toy Robot typically comes with a manufacturer's warranty covering defects in materials and workmanship. Please refer to your purchase receipt for specific warranty details or visit the manufacturer's website for more information.

## FAQs

What is the main purpose of the Lexibook ROB50US Powerman Toy Robot?

The Lexibook ROB50US Powerman Toy Robot is designed to entertain and educate children with interactive features like storytelling, music, quizzes, and remote-controlled movement.

What age group is the Lexibook ROB50US Powerman Toy Robot suitable for?

The Lexibook ROB50US is ideal for kids aged 4 years and above, with a manufacturer-recommended minimum age of 48 months.

What educational features does the Lexibook ROB50US Powerman Toy Robot offer?

The Lexibook ROB50US includes educational quizzes on topics such as numbers, animals, and daily life to make learning fun and engaging.

What type of materials is the Lexibook ROB50US Powerman Toy Robot made from?

The Lexibook ROB50US is made from durable, non-toxic plastic to ensure safety and longevity.

What power source does the Lexibook ROB50US Powerman Toy Robot use?

The Lexibook ROB50US requires 5 AA batteries for the robot and 2 AA batteries for the remote control.

What kind of activities can the Lexibook ROB50US Powerman Toy Robot perform?

The Lexibook ROB50US can dance, play music, move in all directions, tell stories, repeat recorded voices, and shoot foam discs.


What dimensions and weight does the Lexibook ROB50US Powerman Toy Robot have?

The Lexibook ROB50US measures 8.15 x 5.24 x 14.49 and weighs 2.1 pounds, making it compact and lightweight for kids.

How does the Lexibook ROB50US Powerman Toy Robot encourage active play?

The Lexibook ROB50US plays music and has 12 preloaded songs with 2 choreographed dance routines to promote movement and dancing.

#### Video-Lexibook ROB50US Powerman Toy Robot



[Reference link: plus/wp-content/uploads/2024/12/Lexibook-ROB50US-Powerman-Toy-Robot.mp4](#)

[Lexibook ROB50US Powerman Toy Robot User Manual-Device.report](#)

#### References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.