



[Home](#) » [LG](#) » **LG 55EW5P-M Transparent OLED Display User Guide** 

**Contents** [ [hide](#) ]

- [1 LG 55EW5P-M Transparent OLED Display](#)
- [2 Product Usage Instructions](#)
- [3 UNPACKING](#)
- [4 SETTING INSTRUCTION](#)
- [5 Frequently Asked Questions](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)



## LG 55EW5P-M Transparent OLED Display



## Product Usage Instructions

## **Unboxing and Setup**

When unboxing the LG Digital Signage Monitor, ensure all components listed in the manual are present. Follow the step-by-step assembly instructions to set up the monitor securely.

## **Powering On**

Connect the power cable to the monitor and a power outlet. Press the power button on the monitor to turn it on. Follow the on-screen instructions for initial setup.

## **Display Settings**

Adjust the display settings such as brightness, contrast, and color temperature according to your preferences. Access the settings menu using the remote control or buttons on the monitor.

## **Content Playback**

Connect your media source (e.g., USB drive, HDMI device) to the monitor to display content. Use the input selection feature to choose the appropriate source for playback.


## **Remote Control**

Use the included remote control to navigate menus, adjust settings, and control playback. Ensure there is a clear line of sight between the remote and the monitor for proper functionality.

## **Quick Setup Guide**

Please read this manual carefully before operating your set and retain it for future reference.


## **UNPACKING**







A



B



C



E




F

D



G





x 2



H

I


J




K

L


M



x 12  
(M3 x L5.5)




x 4  
(M3 x L5.5)



x 7  
(M3 x L6)

N




x 2

## GUIDE LINE







Worldwide: [www.lg.com/id-manual](http://www.lg.com/id-manual)

SuperSign : <http://partner.lge.com>




## CAUTION



## SETTING INSTRUCTION









1




## WARNING


1 = 1



2




A




180°

B




3


A-1




A-2



B-1




B-2













4




5








## REMOTE BATTERY



## POWER BUTTON



## Frequently Asked Questions


### **Q: How do I reset the monitor to factory settings?**

**A:** To reset the monitor to factory settings, access the settings menu, navigate to the reset option, and confirm the reset action.

### **Q: Can I schedule content playback on the LG Digital Signage Monitor?**

**A:** Yes, you can schedule content playback using the scheduling feature in the monitor's settings menu. Set specific times for content to display automatically.

## Documents / Resources



## [LG 55EW5P-M Transparent OLED Display \[pdf\]](#) User Guide

55EW5P-M, LW550JUL HR A3, 55EW5P-M Transparent OLED Display, T ransparent OLED Display, OLED Display, Display

## References

- [User Manual](#)

📁 LG

💎 55EW5P-M, 55EW5P-M Transparent OLED Display, Display, LG, LW550JUL HR A3, OLED Display, Transparent OLED Display

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

## Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.