



# LG OLED42C4 Oled Evo C4 Tv With Webos Instruction Manual

[Home](#) » [LG](#) » LG OLED42C4 Oled Evo C4 Tv With Webos Instruction Manual 

## Contents

- 1 LG OLED42C4 Oled Evo C4 Tv With Webos
- 2 Specifications
- 3 Product Usage Instructions
- 4 FAQ
- 5 SAFETY PRECAUTION
- 6 PARTS
- 7 WHATS IN BOX
- 8 MOUNTING
- 9 PORTS
- 10 REMOTE CONTROL
- 11 DIMENSION
- 12 Documents / Resources
  - 12.1 References



**LG OLED42C4 Oled Evo C4 Tv With Webos**



## Specifications

- Models: OLED42C4\*, OLED48C4\*, OLED55C4\*, OLED65C4\*, OLED77C4\*, OLED83C4\*
- Weight:
  - OLED42C4\*: 10.1 kg (22.2 lbs)
  - OLED48C4\*: 16.8 kg (37.0 lbs)
  - OLED55C4\*: 16.0 kg (35.2 lbs)
  - OLED65C4\*: 18.5 kg (40.7 lbs)
  - OLED77C4\*: 27.1 kg (59.7 lbs)
  - OLED83C4\*: 41.6 kg (91.7 lbs)
- Dimensions:
  - Width: 577 mm (22.7 inches) – 1,851 mm (72.8 inches)
  - Height: 230 mm (9.0 inches) – 279 mm (10.9 inches)
  - Depth: 41.1 mm (1.6 inches) – 55.3 mm (2.1 inches)
- Power Consumption: 175 W – 700 W
- VESA Mount:
  - OLED42C4\*, OLED48C4\*, OLED65C4\*: 300 x 200 mm
  - OLED55C4\*, OLED77C4\*: 400 x 400 mm
  - OLED83C4\*: 180 x 55 mm

## Product Usage Instructions

### Assembly:

1. Identify the parts labeled a, b, x, QU, etc.
2. Follow the provided diagram for assembly instructions.
3. Use the specified screws and tools for each component.

### Mounting:

1. Choose a suitable location for mounting the TV.
2. Ensure the VESA mount pattern matches the TV and the bracket.

3. Securely attach the TV to the wall or stand following the manufacturer's guidelines.

### **Connection:**

1. Connect the power cord to a power outlet.
2. Connect external devices using the available ports (HDMI, USB, etc.).
3. Power on the TV and follow the on-screen setup instructions.

### **FAQ**

#### **Q: How do I clean the screen of the TV?**

A: Use a microfiber cloth slightly dampened with water to gently wipe the screen. Avoid using harsh chemicals or abrasive cleaners.

#### **Q: Can I wall-mount all models listed?**

A: Yes, all models support VESA mounting; ensure you have the correct bracket for your TV size.





#### **Q: What is the power consumption range for these TVs?**

A: The power consumption ranges from 175 W to 700 W depending on the model and usage.


### **SAFETY PRECAUTION**




### **PARTS**




**WHATS IN BOX**




**MOUNTING**





## PORTS




**42/48"**

AUDIO/HEADPHONE OUT /  
SORTIE POUR CASQUE D'ÉCOUTE/AUDIO



OPTICAL DIGITAL AUDIO OUT / SORTIE AUDIO NUMÉRIQUE OPTIQUE




IR Blaster / Émetteur à infrarouge



## REMOTE CONTROL




## DIMENSION




mm (inches / pulgadas / po)  
kg (lbs / libras / lb)

	A	B	C	D	E	F	F - G	
<b>OLED42C4*</b>	932 mm (36.6) inches	577 mm (22.7) inches	170 mm (6.6) inches	540 mm (21.2) inches	41.1mm (1.6) inches	10.1 kg (22.2) lbs	9.8 kg (21.6) lbs	175 W
<b>OLED48C4*</b>	1 071 mm (42.1) inches	675 mm (26.5) inches	230 mm (9.0) inches	618 mm (24.3) inches	46.9 mm (1.8) inches	16.8 kg (37.0) lbs	14.9 kg (32.8) lbs	223 W
<b>OLED55C4*</b>	1 222 mm (48.1) inches	757 mm (29.8) inches	230 mm (9.0) inches	703 mm (27.6) inches	45.1 mm (1.7) inches	16.0 kg (35.2) lbs	14.1 kg (31.0) lbs	332 W
<b>OLED65C4*</b>	1 441 mm (56.7) inches	880 mm (34.6) inches	230 mm (9.0) inches	826 mm (32.5) inches	45.1 mm (1.7) inches	18.5 kg (40.7) lbs	16.6 kg (36.5) lbs	441 W
<b>OLED77C4*</b>	1 711 mm (67.3) inches	1 035 mm (40.7) inches	267 mm (10.5) inches	982 mm (38.6) inches	47.1 mm (1.8) inches	27.1 kg (59.7) lbs	23.5 kg (51.8) lbs	632 W
<b>OLED83C4*</b>	1 851 mm (72.8) inches	1 092 mm (42.9) inches	279 mm (10.9) inches	1 062 mm (41.8) inches	55.3 mm (2.1) inches	41.6 kg (91.7) lbs	32.3 kg (71.2) lbs	700 W




mm (inches / pulgadas / po)

A	B	C x D	E	F	G	H
OLW480B	OLED42C4*	300 x 200 mm (11.8 x 7.8) inches	M6	263 mm (10.3) inches	≥1.5 m (59.0) inches	113 mm (4.4) inches
	OLED48C4*			126 mm (4.9) inches		118 mm (4.6) inches
	OLED55C4*			523 mm (20.5) inches		121 mm (4.7) inches
	OLED65C4*			633 mm (24.9) inches		121 mm (4.7) inches
WB24GCB	OLED77C4*	400 x 400 mm (15.7 x 15.7) inches		769 mm (30.2) inches		121 mm (4.7) inches
	OLED83C4*			902 mm (35.5) inches		113 mm (4.4) inches



mm (inches / pulgadas / po)

A	B	C x D
WB21EB	OLED83C4*	180 x 55 mm (7.0 x 2.1) inches



\* : 0~9, A~Z

[www.lg.com](http://www.lg.com)


Printed in Korea

Imprimé en Corée



\* M F L 7 2 0 6 3 0 5 7 2 4 0 4 R E V 0 5 \*

Documents / Resources



[LG OLED42C4 Oled Evo C4 Tv With Webos](#) [pdf] Instruction Manual  
OLED42C4, OLED48C4, OLED55C4, OLED65C4, OLED77C4, OLED83C4, OLED42C4 Oled  
Evo C4 Tv With Webos, OLED42C4, Oled Evo C4 Tv With Webos, Tv With Webos, With Webos,  
Webos

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.