

 **Lifesmart**
HPC-F2014YL 31 Inch Tower
Heater with Flame Feature



Lifesmart HPC-F2014YL 31 Inch Tower Heater with Flame Feature Owner's Manual

[Home](#) » [LifeSmart](#) » Lifesmart HPC-F2014YL 31 Inch Tower Heater with Flame Feature Owner's Manual 

Contents

- [1 Lifesmart HPC-F2014YL 31 Inch Tower Heater with Flame Feature](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions \(FAQ\)](#)
- [5 OVERVIEW](#)
- [6 PRODUCT SPECS](#)
- [7 CONTAINER INFO](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



Lifesmart HPC-F2014YL 31 Inch Tower Heater with Flame Feature



Product Specifications

- **LIFESMART SKU:** HPC-F2014YL
- **UPC#:** 810078861959
- **Product Dimensions:** 9.69L x 9.65W x 30.83H, Weight: 6.15lb
- **Master Carton Dimensions:** 7.8L x 7.6W x 32.25H, Weight: 6.44LBS

Product Usage Instructions

Unboxing and Assembly

When you receive your 31-Inch Tower Heater with Flame Feature, carefully unbox the product and ensure all parts are included. Follow the assembly instructions provided in the user manual to set up the heater/stove.

Powering On the Heater

Before plugging in the heater, make sure it is placed on a stable, flat surface away from any flammable materials. Connect the heater to a power source and use the control panel to power it on.

Adjusting Settings

Use the control panel or remote control (if included) to adjust the temperature settings, fan speed, and flame feature according to your preferences. Ensure proper ventilation in the room when using the heater.

Safety Precautions

Always supervise the heater while in use and keep it away from children and pets. Do not block the air intake or exhaust areas of the heater to prevent overheating.

Frequently Asked Questions (FAQ)

- **Can this heater/stove be used outdoors?**

No, this heater/stove is designed for indoor use only.

- **How do I clean the heater/stove?**

Ensure the heater is disconnected from power before cleaning. Use a soft, damp cloth to wipe the exterior of the heater. Do not use abrasive cleaners.

- **What should I do if the heater/stove malfunctions?**

If you experience any issues with the heater/stove, immediately disconnect it from power and refer to the user manual for troubleshooting steps. If problems persist, contact customer support.

OVERVIEW

- **LIFESMART SKU:** HPC-F2014YL
- **UPC#:** 810078861959
- **Product Dimensions:** (L x W x H, Weight) 9.69"L x 9.65"W x 30.83"H, 6.15lb

PRODUCT SPECS

- Powerful Heating:
 - Long-lasting PTC heating element
 - Two heat settings: 1,000w/1,500w
 - Fan Only Mode
 - Safety Features:
 - Overheat safety switch
 - Tip-over safety switch
 - Cooltouch exterior cabinet
- Additional Features:
 - Realistic flame effect
 - Thermostat controlsystem
 - Oscillation function
 - Remote Control Included
 - 24Hour Auto-Off Timer
 - Digitalthermostat controlsystem
 - 1-year limited warranty
 - some assembly required

CONTAINER INFO

Master Carton Dimensions: (L x W x H, Weight) 7.8"L x 7.6"W x 32.25"H, 6.44LBS

Documents / Resources



[Lifesmart HPC-F2014YL 31 Inch Tower Heater with Flame Feature](#) [pdf] Owner's Manual HPC-F2014YL, HPC-F2014YL 31 Inch Tower Heater with Flame Feature, 31 Inch Tower Heater with Flame Feature, Tower Heater with Flame Feature, Heater with Flame Feature, Flame Feature

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.