

LifThor Phantom 4 Tripltek Mount User Manual

Home » LifThor » LifThor Phantom 4 Tripltek Mount User Manual



LifThor Phantom 4 TripItek Mount User Manual



Contents

- 1 Content
- 2 How To Assemble
- 3 Documents /
- **Resources**
 - 3.1 References
- **4 Related Posts**

Content

• Tablet clamp Compatible with 7.9" up to 13" devices



Mounting bracket



• Screws (x2) & washer



• Hex Key (x2)



How To Assemble

Remove the OEM bracket from the Remote control with the help of a screwdriver. (not included).



With the tips of your fingers unscrew the rear support of the bracket to remove the OEM bracket.



Align the LifThor Lite mounting bracket and secure lightly with the smaller screw with the smaller Hex Key (Allen key) provided.



Secure the rear end of the bracket with the bigger screw and washer provided, once secured in place tighten the front screw by pushing down the bracket to align properly.



Unscrew the tightening ring from the back of the tablet clamp and place it on the ball joint.



Attach the clamp to the ball joint and screw the ring back to secure the clamp position / angle.



The clamp has two mechanisms to ensure your tablet sit secure and in place.

The first mechanism is the ratchet part, to adjust to the size of your tablet. We recommend setting it a little smaller (1" / 2.5cm) than the actual size of the table for a tighter, secure fit.





Place the tablet in landscape mode by pulling the spring mechanism upwards and release it to secure the tablet in place. You can adjust the top clamp brackets, if needed, to avoid pressing on any buttons.







Documents / Resources



<u>LifThor Phantom 4 TripItek Mount</u> [pdf] User Manual Phantom 4, TripItek Mount

References

• LifThor Manuals | LifThor Tablet Holders by Thor's Drone World

Manuals+,